

Report no.: 2000.080	ISSN 0800-3416	Grading: Open
Title: Gold resources on Ringvassøy, Western Troms-IV: Regional geochemistry of B- and C-horizon of till.		
Authors: Tor Erik Finne		Client: Troms fylkeskommune/NGU
County: Troms		Commune: Tromsø, Karlsøy
Map-sheet name (M=1:250.000) Helgøy and Tromsø		Map-sheet no. and -name (M=1:50.000) 1534-1 Reinøya, 1534-4 Ringvassøya, 1535-2 Helgøya, 1535-3 Rebbenesøya
Deposit name and grid-reference:		Number of pages: 78 Price (NOK): 450 Map enclosures: 0 <small>=20+(39*10)+1(79-39)</small>
Fieldwork carried out: 01-16.09.1998	Date of report: 01.08.2001	Project no.: 274200 Person responsible:
<b>Summary:</b> This report establishes a link between the various methods employed in geochemical prospecting for gold in the lithologic and topographic regimes present on Ringvassøy; these methods are also used elsewhere in Norway. Samples of the C-horizon from 203 locations in 5 transects across the Ringvassøy Greenstone Belt, and of the B-horizon from 70 of the same sites, were analyzed for Au and 34 other elements. Comparing the results of the B- and C-horizons shows that there is little difference in the geographical distribution between these horizons. The B- and C-samples have a good success rate locating known outcrops of Au ore and of base metal sulfides.  The regional scale mapping conducted by NGU over the last decades succeeds in locating the large scale gold anomalies indicated by the sub-regional and detailed investigations carried out by prospecting companies. A sub-regional approach using B- and C-horizon samples at regular intervals along transects is less successful with reproducing the findings of the detailed study. But this approach unveils anomalies that the sub-regional stream sediment survey did not point out. This was partly because of the lack of streams, but there were also anomalies in the transect soil sampling that were not present in the nearby stream sediments.		
Keywords: Geochemistry	C-horizon	B-horizon
Gold	Till	

## CONTENTS

1. INTRODUCTION.....	5
2. METHODS.....	8
2.1 Fieldwork .....	8
2.2 Sample preparation and analysis.....	8
3. RESULTS.....	10
3.1 Data quality .....	10
3.2 B- horizon vs. C-horizon.....	11
3.3 C-horizon.....	11
4. DISCUSSION .....	12
4.1 Data quality .....	12
4.2 C-horizon and stream sediments .....	12
4.3 B-horizon vs. C-horizon.....	13
4.4 C-horizon and old regional survey.....	17
4.5 B- and C-horizon, anomalies of soil samples (Folldal Verk 1983-84), and soil samples of ASPRO.....	17
4.6 C-horizon and known mineralizations. ....	18
5. CONCLUSIONS.....	21
6. REFERENCES.....	22

## FIGURES

Figure 1. Overview map of northern Ringvassøy. ( <i>next page</i> ) .....	6
Figure 2. Scatterplot matrix of B- and C-horizon analyses for 35 elements.....	14
Figure 3. Relative proportion of Au in B- and C-horizon along transect T1 and T2. ....	15
Figure 4. Relative proportion of Au in B- and C-horizon along transect T3 and T4. ....	16
Figure 5. Concentrations of gold in 4 samples from the 1986 regional survey and corresponding values for samples from approximately same sites of this study. ....	17
Figure 6. Gold concentrations in ore samples (hexagons) and the B- and C-horizon (circles). ( <i>next page</i> ). ....	19

## TABLES

Table 1. Descriptive statistics of Au in till and stream sediments from Nordland/Troms regional study, the subset Ringvassøy, and of ore samples from Tromsø and Karlsøy municipalities.....	5
Table 2. Elements determined in the samples of B- and C-horizon from Ringvassøy, the detection limits, and proportion of samples reported below detection limit.....	9
Table 3. Correlation coefficients (r) of the 19 pairs of field duplicates.....	10

## **APPENDIX**

Appendix 1            1p  
Plot of analytical results for laboratory standard

Appendix 2            2p  
Plot of analytical results for field duplicates.  
Listing of analytical results for field duplicates.

Appendix 3            9 p  
Bar diagrams depicting analytical result of B- and C-horizon samples along four transects for Ag, Al, As, Au, B, Ba, Bi, Ca, Cd, Co, Cr, Cu, Fe, Ga, Hg, K, La, Mg, Mn, Mo, Na, Ni, P, Pb, Sb, Se, Sr, Te, Th, Ti, Tl, U, V, W, and Zn.

Appendix 4            4 p  
Listing of analytical results for B- and C-horizon samples

Appendix 5            4 p  
Listing of analytical results for all C-horizon samples

Appendix 6            36p  
Sample site number map  
Point maps for B- and C-horizon samples, showing concentration of Ag, Al, As, Au, B, Ba, Bi, Ca, Cd, Co, Cr, Cu, Fe, Ga, Hg, K, La, Mg, Mn, Mo, Na, Ni, P, Pb, Sb, Se, Sr, Te, Th, Ti, Tl, U, V, W, and Zn.

## 1. INTRODUCTION

The island of Ringvassøy has long caught the interest of prospectors and miners, for the last 30 years with the focus mainly on gold. The island covers around 650 km<sup>2</sup>, and is situated a short distance north of Tromsø, on the northern coast of Troms county, Northern Norway. It is also widely known for its rich grouse population, but from the soil geochemist's point of view, the hunting's contribution of lead to the soil over the years is more a "nugget" problem than anything else.

Following the more than 130 years of mining and prospecting, a large number of data sets are available for the island of Ringvassøy. The Geological Survey of Norway (NGU) has seen a need for compiling the most important data to aid the understanding of gold occurrence in this area. Partial financial support for this activity was provided by Troms County through the County Geologist.

Sandstad and Nilsson (1998) report in great detail the universities' and prospecting companies' activities since the 1970's, as well as bedrock and mineral resource mapping carried out by NGU in the period 1973 - 1994. Conclusions of the mentioned investigations are brought forward, and the report also contains observations from the authors' field visit in August 1997 and analytical results of 44 bedrock/ore samples collected at that time.

In addition, a regional geochemical survey covering Nordland and Troms counties in 1986 covered the island with 14 sampling sites (Ekremsæter, 1988, and Kjeldsen and Ottesen, 1988). Samples of stream sediments and of C-horizon of till were analysed for gold (and a score of other elements). The eight samples taken within the area of Ringvassøy that has been most intensively prospected, show the following enrichment:


Sample medium	Till regional study		Stream sediment regional study		NGU Ore database
Area	Nordland/Troms	Ringvassøy	Nordland/Troms	Ringvassøy	Tromsø + Karlsøy
N	1047	8	1298	8	123
Max	163	54	187	10.4	37371
Min	1	1	0	2.6	-
Avg	4	21	3.97	4.61	584
Median	1	17	2.7	3.8	32

**Table 1.** Descriptive statistics of Au in till and stream sediments from Nordland/Troms regional study, the subset Ringvassøy, and of ore samples from Tromsø and Karlsøy municipalities.

Figure 1 shows Northern Ringvassøy, its lithology and location of various prospecting activities. The prospecting companies (ASPRO/Sulfidmalm and Folldal Verk AS/Amoco Norway) obtained a high number of anomalies in a 300 km<sup>2</sup> stream sediment survey, and from their detailed investigations by means of soil sampling and heavy mineral concentration of soil. NGU's regional mapping also shows an obvious enrichment of gold on the island. However, knowledge on how the results of the methods correlate was not available, and to improve interpretation of both the local data sets of Ringvassøy as well as the regional data sets, a geochemical mapping project was designed. Initially a sampling grid of 1x1 km was planned for most of the Northern part of Ringvassøy, covering approximately 350 km<sup>2</sup>. Due to financial limitations, the project had to reduce field and/or analytical cost. It was not

considered feasible to reduce on sampling density, and a reduction of the investigated area would not give results bringing together all the detailed prospectors' results. A compromise was denser sampling along transects crossing the Ringvassøy Greenstone Belt (RGB), in addition to some samples to verify the four highest gold values of the regional study. The transects were laid out roughly by Peter Ihlen, NGU, whereas the details were determined by the local conditions, the location of earlier prospecting areas, and by financial restrictions.

Figure 1. Overview map of northern Ringvassøy. (*next page*)



## **2. METHODS**

### **2.1 Fieldwork**

Sample sites were planned along five transects of varying length, crossing the RGB and passing some of the interesting anomalies found by the prospecting companies. Sampling interval was set to 200 m along the transects, and about 200 sites were planned. Chartering a local boat speeded up access to the sites on the SW side of Skogsfjordvatn. Obtaining evenly distributed locations, only 200 m apart, along (straight line) transects called for good quality real time navigation. A differential GPS signal radio (Garmin GBR 21) was employed together with an ordinary handheld GPS unit (Garmin 12CX). This set-up significantly decreased time spent on navigation, particularly during the 3-4 days when sea fog reduced visibility to 10 m. The radio beacon is located at the Torsvåg lighthouse, Vannøya, some 30 km north of Ringvassøy. Using a DGPS system greatly reduced positioning error compared to ordinary GPS, as the "noise" imposed by Pentagon (SA) was not lifted from the GPS satellite signals in 1998. The planned transects were plotted on maps prior to the fieldwork, and used to check progress in the field. Øystein Jæger and Tor Erik Finne, NGU, carried out fieldwork during the period 01-16.09.2001. Travelling by pick-up truck and on foot, the average number of sample sites visited per field day was 17.

Upon arrival at the sampling site, a hole was dug using a paint free steel spade, usually to a depth of about 35 cm, rarely deeper than 60 cm, where the C-horizon of the usually well-developed podzol soil was encountered. Picking out pebbles, a sample of about 4 dl was taken from the C-horizon and stored in white plastic containers. None of the field workers wore any jewellery during the field period. From a number of sites, a sample of the B-horizon was also collected. Furthermore, from every 10<sup>th</sup> site a duplicate sample was collected, some 20 m away from the regular sample. Upon storing coordinates in the GPS, they were also read from the GPS display and noted on the field observation card, together with observed thickness of humus, thickness of bleached layer and depth to the top of C-horizon.

### **2.2 Sample preparation and analysis.**

At NGU, the samples were left to dry in the original sample container, only taking off the lid, and checking that sample numbering was legible. Drying temperature was below 40 °C. After drying, the samples were split and sieved on nylon sieves to obtain a minimum of 25 g sample <0.06 mm. Weight of split and fine fraction was recorded, thereby giving a rough indication of the samples' grain size. The fine fraction was wrapped in mini-grip plastic bags, whereas the coarse fraction of the split was discarded. Before shipping the samples to ACME Analytical Laboratories in Vancouver, they were put in random order together with small sample sets from other investigations. Sample numbering after randomisation was 10303 – 10603 inclusive; a total of 329 samples derived as follows:

Type	Number
C-horizon, regular samples	203
C-horizon, field duplicates	19
B-horizon regular samples	68
B-horizon, field duplicates	3

C-horizon from Reisa, 1998	9
Samples for reanalysis, sampled 1997	10
Overbank sediments from Ethiopia	17
SUM	329

ACME performed an Aqua Regia extraction on of 20 g of sample material, and analysed the samples for 33 elements by ICP-AES and *Ultrasonic ICP*, by graphite furnace AAS (Au only), and by cold vapor AAS (Hg only). Elements determined and their detection limits are given below in ppm unless otherwise stated:

Al	Ag	As	Au	B	Ba	Bi	Ca	Cd	Co	Cr	Cu
100	30ppb	0,5	0,2ppb	3	1	0,1	100	10ppb	1	1	0,2
0	25.8	0.3	5.4	55	0	82	0	10	0	0	0
Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	Ni	P	Pb
100	0,5	10ppb	100	1	100	2	0,1	100	1	10	0,3
0	0	7.2	0.3	0.3	0	0	2	3.7	0	0	0
Sb	Se	Sr	Te	Th	Ti	Tl	U	V	W	Zn	Element
0,2	0,4	1	0,2	2	100	0,2	4	1	2	1	Det.Lim.
37.8	8.9	0	80.5	57.3	0	75.6	66.8	0	88.8	0	%age<DL

**Table 2.** Elements determined in the samples of B- and C-horizon from Ringvassøy, the detection limits, and proportion of samples reported below detection limit

A number of samples contained element concentrations that were reported below the determination limit (DL) for the analytical method. For a number of elements, all samples were above DL, but for Bi, Te, and Tl, more than 75% of the samples analyzed were reported below DL. Details are given in Table 2. In order to provide numbers for further processing, all results reported below DL were replaced by a value equal to 0.5\*DL for the element in question.

The analytical results were linked with sample information to yield data sets for evaluation of data quality, comparison of the two sampled horizons, as well as for producing maps. Data on 375 stream sediment samples collected in 1982 by Folldal Verk AS throughout the RGB (Krause, 1983) was compiled from paper maps of scale 1:50,000 into an electronic map with approximate coordinates (only for Au and Ag).

### 3. RESULTS

The transects are numbered T1 – T5, and have their defined starting point at the Southernmost or Westernmost end. Location of the transects, sample sites of the 1986 survey, location of samples from the ore database at NGU, stream sediment sites and detailed mapping areas of Folldal Verk are all shown in Figure 1 together with geographic place names.

#### 3.1 Data quality.

No standard sample was included with this analytical batch. However, the laboratory routinely analyses and reports its own standard, in this case named STANDARD DS2/C3/AU-S. The results 10 analyses of this standard, evenly distributed throughout the analytical batch are shown in Appendix 1. According to this, all elements determined have acceptable values for the standard sample throughout the batch, with the exception of K, Cd, and U, that all have one reading slightly out of bounds. The inclusion of this standard sample material is part of the quality control implemented by the laboratory, and results not meeting the quality criteria most likely would trigger a re-make in the lab, rather than being reported to the customer.

Field duplicates are considered the best measure of describing the reproducibility of a geochemical map. Field duplicates of the C-horizon were collected from 19 sample sites with approximately 20m between the two sample pits in a pair. The analytical results of these pairs are given in the listing of Appendix 2, as well as a matrix of scatterplots in the same Appendix. As there were only 3 duplicate pairs of the B-horizon samples, these were not given any special treatment.

The scatterplots of field duplicates for the 35 elements show that only a few of the elements have a very good reproducibility. With only 19 pairs of field duplicates, using a simple correlation coefficient (**r**) (Table 3) as a measure of reproducibility in this case is not recommendable, as small variations in distribution pattern can bring up large differences in the calculated coefficient. To illustrate this; consider the scatterplots for Cr and Ti, and their corresponding **r**'s; .78 and .56. Judging from the plots, these two elements would score about the same on reproducibility, Ti perhaps even slightly better. But the calculated **r** says otherwise. The scatterplots show better than any other presentation form how the chances are that a high value really is high, and how often the detection limit of the laboratory has been set too low for this type of sample material (as when a number of sample pairs show values below detection limit and values way above, even extremely high values). The elements behaving like this are Ag, B, Bi, Te, (and W, that lacks variation along the duplicate axis). The plot for Au also has a couple of points on the detection limit, and for all these elements, one should keep this in mind when reading the maps and interpretations given later on.

Ag	Al	As	Au	B	Ba	Bi	Ca	Cd	Co	Cr	Cu
-0.24	0.65	0.63	0.00	-0.03	0.70	-0.07	0.82	-0.13	0.51	0.78	-0.06
Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	Ni	P	Pb
0.66	0.72	0.14	0.61	-0.01	0.75	0.71	0.88	0.76	0.13	0.13	0.74
Sb	Se	Sr	Te	Th	Ti	Tl	U	V	W	Zn	
0.91	-0.13	0.91	-0.03	0.98	0.56	0.15	-0.32	0.63	-	0.76	

**Table 3.** Correlation coefficients (**r**) of the 19 pairs of field duplicates.

### **3.2 B- horizon vs. C-horizon**

Comparison of the results for the two soil horizons is presented primarily as an array of scatterplots in Figure 2, much like that for the field duplicates. Details on how the levels vary along the transects are also seen in the maps, but due to the scale, two variable plots are difficult to read clearly where the sampling intervals are so. As an aid, the bar diagrams of Appendix 3 give the concentrations for B- and C-horizon samples from the four transects where the B-horizon was also sampled. Results for the C-horizon are colored grey, and results for the B-horizon are colored brown. The transect positions are shown in Figure 1. From the bottom up, the diagrams show transect 1-4, and the direction along the X-axis is from SW to NE (transect 1 and 2), from S to N (transect 3) and from W to E (transect 4). Software limitations does not allow for positioning legible bars correctly according to sample sites' distance along the transect. Please recall that B-horizon samples were not collected from all sites along a transect, and that transect 2 is interrupted by the lake Skogsfjordvatnet. A listing of the B and C results is given in Appendix 4.

### **3.3 C-horizon**

Twelve of the samples were collected close to four the sample sites of the regional study of 1986 as a follow-up. Results of these are plotted on the maps, but are also shown in Figure 5 together with the results of the old study. From left to right in the diagram, they are located at Gamvikbukta in the North; at Hessfjorden in the East; at Skogsfjorden in the West; and at Dåfjord in the center.

All results from the C-horizon samples are presented in table format in Appendix 5, and as proportional symbol maps in Appendix 6. However, the first page in Appendix 6 is a map of sample site numbers. The maps also show the features of the most up-to-date digital bedrock map based on the scale 1:250,000. As this information is gathered from the two map sheets Helgøy (Grognan and Zwaan, 1997) and Tromsø (Zwaan et al., 1998), a certain discrepancy is present along the map sheet border. No attempt is made here to join the rock units of the two adjacent maps, but to ensure better readability, the legend is somewhat changed in as much as the same raster is chosen for the rock units that continue across the map limits. The bedrock map is only used as a lithological backdrop, and to increase the readability of the point maps. The legend of the point maps are devised by the ArcView default method "natural breaks", that pays attention to the mapped variable's frequency distribution when assigning upper limits of the groups associated with the map symbols. The maps furthermore include the scatterplot of the field duplicates to assist in evaluating the map. The maps for silver (Ag) and for gold (Au) also show the results of the stream sediment survey conducted by Folldal Verk, and the gold map also shows the values for Au in the C-horizon from the regional study of 1986.

## **4. DISCUSSION**

In the following, reference is made to geographic place names that can be found on the map in Figure 1. The transects are numbered T1 to T5, and have their defined starting point at the southernmost or westernmost end. Ihlen and Furuhug (2001) comment on typical chemistry of bedrock present in the area, and no effort is made here to duplicate this. Surficial deposits in the area are mainly derived from the last glaciation period, and consist mostly of till of varying thickness. The transport distance and direction from the source rock vary, but the maps for Cu, Fe, and V suggest that there has been very little transport because these elements show a sharp and continuing change of concentration when entering into the tonalitic gneiss.

### **4.1 Data quality**

The scatterplots of Appendix 2 give an impression that data have varying quality. Nevertheless, all elements analyzed have been included in the following, but particularly for Ag, B, Ni Se, and Te the quality is either poor or not documented by the present set of duplicates.

### **4.2 C-horizon and stream sediments**

It is important to point out that the absolute figures for gold concentrations in the B- and C-horizons of this study are not directly comparable to those for the stream sediments of Folldal Verk. The natural processes governing the dispersion and the grain sizes collected for analysis are different. Most likely are the extraction and analytical procedure different as well (not stated by Krause).

It is assumed that stream sediments reflect the chemistry of soils upstream; but only that of the active sediment sources as long as recent sediments are sampled. A high correlation between gold in soil samples and single point stream sediment anomalies is not to be expected due to the problem of nuggets. The Folldal Verk stream sediment data, however, exhibit a number of multi-point gold anomalies. Unfortunately, only few of these are in the vicinity of the transects sampled. The best correlation is seen at the start of Transect 1, T1, (its southwestern part), where moderate levels of Au in the streams are found close to the high(est) values of both the B- and C-horizons. Also at the follow-up by Skogsfjorden, both C-horizon and stream sediments have moderate to high levels, and the same goes for the follow-up at Dåfjorden. Also the stream sediment anomaly from the SE bay of Skogsfjordvatnet is matched by an anomalous sample of the 1986 survey, whereas this is not the case across the lake. The stream anomaly at Leirbogdalen is less than one km downstream of T1, but there is no elevation in gold of the B- or C-horizon. The moderate anomalies of T2's NE part are matched by moderate values for stream sediments. The soil C-horizon anomaly at the outlet of Skogsfjordvatnet has no stream sediment samples downstream.

All in all, there is a very good correlation between anomaly areas of these two methods. Krause (1983) states that four people carried out the fieldwork over a period of four weeks. Using stream sediment as a sampling medium is a widely used technique in prospecting. This

work shows that regular sampling of soil at a comparable sampling density yield comparable results, and is achieved at the approximate same input of man-hours. Soil sampling can also be employed where there are no streams available.

#### **4.3 B-horizon vs. C-horizon**

Folldal Verk/Amoco used the precipitation layer of the soil profile as their sampling medium (Cuttle, 1983), and most of NGU's regional projects have used the C-horizon. A comparison of the two horizons' relative metal concentrations based on a large-scale survey is done through the Kola Ecogeochemistry project (Reimann et al, 1998). Median values for the Aqua Regia extracts for most of the elements of interest in gold prospecting, except for gold itself, are found in the Kola atlas. The concentration ratios of the B- and C-horizon samples from Ringvassøy agree well with the data from Kola; usually levels are higher in the C-horizon compared with the B-horizon, except for Fe, Mo, Pb, Se, Ti, and V (Figure 2). The Au concentrations are fairly similar in both soil horizons, but the gold values are usually somewhat higher in the C-horizon. Thus, the approach employed by most of NGU's regional geochemical mapping projects (emphasizing least possible influence by secondary dispersion in the samples of surficial deposits) yield results that are comparable with the results of the prospecting companies that emphasize reliable, but low-cost sampling procedures. The maps in Figure 3 and Figure 4 give a more precise indication of where the B-horizon has higher gold values than the C-horizon. Again, there is no evident clustering of the increased B/C ratio for gold, which leaves the two sampling medias quite comparable.




Figure 2. Scatterplot matrix of B- and C-horizon analyses for 35 elements.




Figure 3. Relative proportion of Au in B- and C-horizon along transect T1 and T2.

ppb Au i B+C hor.

- 0.2 - 6.3
- 6.3 - 12.8
- 12.8 - 20.5
- 20.5 - 55.2
- 55.2 - 134.1

Andel fra B og C

- Au
- Au\_b

Contrib. from B and C




Figure 4. Relative proportion of Au in B- and C-horizon along transect T3 and T4.

#### 4.4 C-horizon and old regional survey.

It was difficult to achieve precise positioning in the field for the four follow-up sites of the 1986 survey. The original locations of the old survey were transferred from maps with a scale 1:50,000 to maps with a scale 1:250,000, and the coordinates were obtained from digitizing these maps. The four-times-three samples that were collected close to the four sites of the old survey only show that the two old values above 10 ppb Au are verified by one of the three follow-up samples at each site. Of the two old samples of values below 10 ppb Au, one was verified to be low, whereas one of the follow-up samples at Skogsfjorden showed the highest Au value of the whole set of twelve.




Figure 5. Concentrations of gold in 4 samples from the 1986 regional survey and corresponding values for samples from approximately same sites of this study.

#### 4.5 B- and C-horizon, anomalies of soil samples (Folldal Verk 1983-84), and soil samples of ASPRO.

Both B- and C-horizon results from this study are used for comparison with the anomalies identified by the Folldal Verk survey. The location numbering used by Sandstad and Nilsson (1998, p18-19 and p 29-31) is also used here, as shown in Figure 1.

1 Sørdalshøgda S and 2 – Kable - Sørdalshøgda N and ASPRO Sørdalshøgda. T3 passes right through these areas. The highest gold value for the C-horizon in this area is 14.2 ppb Au (sample 1450D) and the highest B-sample contains 5.3 ppb Au. Sørdalshøgda is barely visible as an anomaly in this data set.

### 3 Leirbogdalen and 5 Tverrfjellet.

Tverrfjellet is crossed by T1, but the elements Au, Pb or Zn show no anomalies in either of the two horizons. Ag and As also shows up in Folldal Verk's Leirbogdalen; this is not the case in the B- or C- samples of the present study.

### Areas 4, 6, 7 and 8.

Neither of these areas are in the vicinity of any of the transects.

### 9 Nattmålstinden/-vatnet.

This area is not intersected by any of the transects, but lies closest to T1. Folldal Verk's soil samples were anomalous in Au (up to 200 ppb), and Cu, Zn and Pb. Highest Au value along T1 in the vicinity of area 9 is 29.1 ppb (sample 1520D).

### 10 Holmevasshøgda and 11 Saltindbukta.

Neither of these areas are in the vicinity of any of the transects. However, the 1986 survey has a Au-value of 26 ppb located in the center of area 11 Saltindbukta.

### 12 Høgda.

As for area 11, there is no transect in the immediate surrounding. The Au value of the 1986 survey is 40 ppb, and is located about 500 m downhill from Høgda. The Au values for the three follow-up samples from this study, contained between 2.6 and 16.8 ppb Au.

### 13 Blåfjell and ASPRO Hårskoltan.

T5 is adjacent to area 13, which is high in Au, As and Zn, and crosses Hårskoltan. The high As and Zn values are matched by the samples from T5, but not by the Au values.

### 14 Soltindaksla.

The southernmost samples from T3 lie closest to this area to within about one km. No values of interest are found in either horizons, only bedrock analyses are available from Folldal Verk.

Out of four possible matches between results for the soil sample areas of Folldal Verk and for the transects of this study, only one is positive in gold, two if As is included. By including the 1986 survey and follow-ups, three out of six areas support the findings from Folldal Verk survey.


## 4.6 C-horizon and known mineralizations.

A number of analyses were retrieved from the ore database at NGU. A map showing the gold concentrations for these samples as proportional hexagons is presented in Figure 6. This map also shows the gold concentrations in the B- and C-horizon samples as circular symbols.

Anomalous values for the analyzed ores/mineralizations are clearly picked up in two out of four cases; T1 SW and T2 SW of Skogsfjordvatnet. The ore samples from Sørdalshøgda have a median concentration of 113 ppb Au, and also contain the extreme value of the entire data set. The ore sampled 1200 m S of Sørdalshøgda's extreme Au ore values is reflected in a couple of B- and C-horizon samples some 300 m NW of this mineralization, whereas there is no indication in the samples of B- or C-horizons of the extreme Au ore values. Molybdenum (Mo) also occurs at anomalous levels in the ore samples from Sørdalshøgda, and in the B- and

C-horizons as well. Samples along transect T5 do not reflect the moderate Au value for the ore sampled only 200 m south of the transect. However, the As and Sb values are highly elevated for most of this transect, similar to the elevated values for As and Sb in the ore. Another continuous As-Sb anomaly is found at the NE end of T2, where there are also a couple of weak Au anomalies in the C-horizon.

Figure 6. Gold concentrations in ore samples (hexagons) and the B- and C-horizon (circles). (*next page*).



## **5. CONCLUSIONS**

The aim of this project was to establish a link between the various methods employed in geochemical prospecting for gold in the lithologic and topographic regimes present on Ringvassøy.

The regional scale mapping conducted by NGU over the last decades succeeds in locating the large-scale gold anomalies indicated by the sub-regional and detailed investigations carried out by exploration companies. A sub-regional approach, collecting the C-horizon at regular sampling intervals along transects, is less successful in reproducing the findings of the detailed study. But this approach unveils anomalies that the sub-regional stream sediment survey did not point out. This is partly due to the lack of streams, but there were also anomalies in the transect soil sampling that were not found in the nearby stream sediments.

Comparing the results for samples of the B- and C-horizon from 70 sites, there is little difference in the geographical distribution of the various elements.

## **6. REFERENCES**


- Ekremsæter, J. 1988. Geokjemisk kartlegging i Nordland og Troms. Dokumentasjon av totalinnholdet av grunnstoffer i bekkesedimentenes finfraksjon (NAA analyse). (In Norwegian). NGU-rapport 87.178. 72pp.
- Cuttle, J. 1983. Ringvassøy project. Bergvesenet rapport 2957. 28pp. Map enclosures in Bergvesenet rapport 2958.
- Grogan, P.W. and Zwaan, B.K. 1997. Berggrunnsgeologisk kart Helgøy, scale 1:250,000. NGU.
- Ihlen, P. and Furuhaug, L. 2001. Gold resources on Ringvassøy, western Troms-III: Geochemistry of heavy-mineral concentrates from stream sediments and potential gold sources. NGU-report 2000.059. 104pp
- Kjeldsen, S. and Ottesen, R.T. 1988. Geokjemisk kartlegging i Nordland og Troms. Data for innholdet av gull i løsmassenes finfraksjon.(In Norwegian). NGU-rapport 88.084. 17pp.
- Krause, M. 1983. Summary report 1982, Ringvassøy project. Bergvesenet rapport BV 2967.
- Reimann C., Äyräs M., Chekushin V. A., Bogatyrev I., Boyd R., Caritat P. De, Dutter R., Finne T. E., Halleraker J. H., Jæger Ø., Kashulina G., Niskavaara H., Lehto O., Pavlov V., Räisänen M. L., Strand T. And Volden T., 1998. Environmental Geochemical Atlas of the Central Barents Region. NGU – GTK – CKE special publication. Geological Survey of Norway, Trondheim, Norway. 745 s.
- Sandstad, J. S. and Nilsson, L.P. 1998. Gullundersøkelser på Ringvassøy, sammenstilling av tidligere prospektering og feltbefaring i 1997. (In Norwegian). NGU rapport 98.072. 68pp.
- Zwaan, K.B., Fareth, E., and Grogan, P.W. 1998. Berggrunnsgeologisk kart Tromsø, scale 1:250,000. NGU.

# Standards Report

Project:  
Scientist:  
Project date:

Batch: Res98C  
Standard: DS2C3AU  
Report date: 2001/07/16

Fail: ● Default +/- 2 std. dev.  
Pass: ○  
Historic: •




**Duplicates Report**

NGU


Project: Ringvassøy Geochemistry  
 Scientist: T E Finne  
 Project date: 2001/07/20


Batch: Res98C  
 Duplicate: Duplicate  
 Report date:


Tol: ● +/-20 %  
 Pass: ●  
 Historic: ●





Sample	FD	mE49gs	mN34gs	Random	Fine	Ag	Al	As	Au	B	Ba	Bi	Ca	Cd	Co	Cr	Cu	Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	P	Pb	Sb	Se	Sr	Te	Ti	U	V	W	Zn
1410	0	441597	7764002	10395	23.0	222.0	4.64	58.1	4.0	1.5	1.40	0.50	0.08	0.11	52.0	175.0	181.9	8.37	12.5	57.0	0.02	4.0	2.50	1889	0.6	103.0	0.065	1.9	11.50	1.90	4.0	2.5	193.0	1.0	98.87		
1410	1	441597	7764002	10656	24.5	36.0	3.89	3.3	5.0	0.20	0.50	0.14	0.07	46.0	141.0	222.9	8.36	16.3	63.0	0.04	5.0	2.50	2291	0.3	101	94.0	0.070	20.0	13.20	0.90	4.0	1.0	113.4				
1420	0	439598	7763998	10407	19.0	70.61	8.16	3.61	1.0	0.11	0.13	0.00	0.00	94.0	84.6	85.5	10.9	55.0	0.17	4.0	1.75	2159	0.9	0.01	94.0	0.059	2.7	5.80	0.40	4.0	1.0	156.0					
1420	0	439598	7763998	10611	22.1	49.0	3.03	119.1	3.6	1.5	0.80	0.10	0.18	0.30	52.0	91.0	282.9	7.30	58.0	0.08	12.0	1.70	1941	0.2	0.01	94.0	0.045	3.1	8.50	0.40	4.0	1.0	112.8				
1430	0	445998	7764001	10533	19.2	15.0	2.53	19.5	1.2	3.0	0.18	0.15	0.05	0.05	37.0	78.0	108.7	4.8	5.8	32.0	0.06	9.0	1.31	1223	0.4	0.01	52.0	0.082	4.4	1.60	0.00	1.0	1.0	92.0			
1430	1	445998	7764001	10393	23.0	37.1	2.57	71.2	4.0	1.5	1.80	0.10	0.18	0.05	100.0	126.0	337.1	7.10	10.4	73.0	0.015	35.0	2.06	1515	0.3	0.01	101.0	0.069	4.0	6.20	0.80	1.0	1.0	91.5			
1440	0	447601	7763985	10655	15.3	65.0	1.67	12.5	0.20	0.18	0.16	0.06	0.01	100.0	36.0	102.9	11.22	3.2	78.0	0.03	53.0	0.30	2386	1.3	0.01	105.0	0.131	59.7	1.80	2.00	1.0	1.0	167.7				
1440	1	447601	7763985	10404	32.5	21.3	8.3	1.5	0.20	0.18	0.16	0.06	0.01	100.0	74.0	45.4	5.01	6.9	22.0	0.12	17.0	1.30	1462	0.7	0.01	54.0	0.081	12.8	1.80	0.50	1.0	1.0	90.0				
1450	0	437501	7764004	10484	21.1	85.0	3.18	5.1	3.4	12.0	0.60	0.10	0.39	0.05	31.0	32.0	77.3	8.43	12.9	7.0	2.65	87.3	7.0	0.01	165.0	0.069	3.8	2.10	0.80	1.0	1.0	138.7					
1450	1	437501	7764004	10394	25.0	91.0	3.63	4.3	14.2	1.6	0.60	0.11	0.06	0.01	100.0	170.0	174.8	7.40	9.7	17.0	0.17	6.0	2.52	1158	7.1	0.02	102.0	0.053	2.8	1.40	0.80	1.0	1.0	164.1			
1460	0	437501	7764001	10390	34.7	53.0	2.51	31.8	5.3	1.5	27.0	0.20	0.29	0.14	47.0	92.0	202.3	5.98	6.9	11.0	0.03	7.0	1.66	906	0.5	0.02	58.0	0.022	7.9	1.30	0.00	1.0	1.0	85.6			
1460	1	437501	7764001	10450	23.0	45.3	1.50	18.3	4.4	1.2	0.20	0.25	0.13	0.05	12.0	10.0	27.0	79.0	86.3	4.8	7.4	13.0	0.03	5.0	1.45	197	0.3	0.02	47.0	0.032	4.4	1.50	0.40	1.0	1.0	64.6	
1470	0	437500	7762900	10503	37.3	71.0	1.40	12.2	4.5	1.8	0.10	0.33	0.05	25.0	52.0	82.0	3.26	25.0	0.02	9.0	1.83	559	0.2	0.02	31.0	0.082	1.3	1.20	0.50	1.0	1.0	73.0					
1470	1	437500	7762900	10376	31.2	166.0	1.58	18.3	2.96	1.5	0.50	0.38	0.28	0.20	33.0	33.0	178.3	3.22	4.9	11.0	0.02	11.0	0.83	639	0.4	0.02	43.0	0.087	2.1	2.50	0.30	1.0	1.0	53.7			
1480	0	430300	7768578	10563	46.7	42.2	12.5	3.9	3.0	1.5	0.10	0.16	0.04	34.0	96.0	63.0	0.10	5.6	0.04	109.3	5.39	7.6	11.0	0.17	84.5	0.7	0.02	63.0	0.085	15.0	0.15	0.40	1.0	1.0	90.6		
1480	1	430300	7768578	10490	40.0	18.0	2.46	23.1	9.8	6.0	0.30	0.17	0.07	0.01	100.0	101.3	113.1	5.18	7.7	6.0	0.03	6.0	2.03	614	0.7	0.03	66.0	0.085	19.0	3.40	0.40	1.0	1.0	84.4			
1490	0	428385	7767721	10476	25.0	15.0	2.55	21.3	7.9	5.0	0.20	0.26	0.05	0.05	35.0	88.0	178.3	3.92	5.3	22.0	0.04	7.0	1.27	510	0.6	0.02	54.0	0.078	3.0	1.10	0.30	1.0	1.0	52.5			
1490	1	428385	7767721	10476	25.4	38.0	2.61	7.7	4.5	3.0	1.10	0.20	0.28	0.02	100.0	88.0	88.0	3.67	3.08	0.03	5.0	1.27	510	0.4	0.02	42.0	0.080	1.6	0.20	1.20	0.0	1.0	81.0				
1500	0	428337	7766900	10419	68.1	15.0	1.59	8.5	2.1	1.5	16.0	0.10	0.25	0.01	13.0	72.0	101.9	2.64	5.7	65.0	0.06	5.0	0.74	197	0.6	0.02	22.0	0.039	2.6	1.10	0.20	1.0	1.0	78.0			
1500	1	428337	7766900	10585	20.4	50.0	2.07	30.2	5.5	1.5	13.0	0.10	0.22	0.03	19.0	67.0	168.3	4.14	6.7	30.0	0.04	7.0	1.44	194	0.7	0.02	21.0	0.039	2.7	1.20	0.20	1.0	1.0	70.0			
1510	0	424729	7765347	10422	24.2	76.0	3.12	2.7	1.6	3.0	1.40	0.24	0.04	0.01	20.0	70.0	124.8	3.51	4.7	78.0	0.04	8.0	1.64	327	0.8	0.02	61.0	0.051	5.6	1.20	0.20	1.0	1.0	70.5			
1510	1	424729	7765347	10508	21.0	40.0	1.82	3.0	5.0	1.0	0.14	0.14	0.01	8.0	45.0	68.9	2.89	4.9	23.0	0.04	4.0	1.35	367	0.4	0.01	30.0	0.045	3.6	1.10	0.20	1.0	1.0	84.0				
1520	0	422919	7764831	10626	15.8	15.0	1.58	11.5	5.6	3.0	1.10	0.14	0.01	8.0	40.0	12.0	65.6	2.59	8.3	16.0	0.05	14.0	0.75	374	2.9	0.03	29.0	0.045	3.0	1.20	0.20	1.0	1.0	83.6			
1520	1	422919	7764831	10346	15.0	12.4	1.63	5.6	2.9	1.5	25.0	0.10	0.36	0.03	12.0	45.0	63.5	2.69	3.6	14.0	0.05	6.0	1.70	1355	0.2	0.02	29.0	0.045	6.1	1.60	0.20	1.0	1.0	53.4			
1530	0	441667	776932	10521	16.6	16.0	2.34	6.1	1.5	1.6	0.10	0.27	0.03	12.0	45.0	76.0	7.98	9.8	29.0	0.02	23.0	0.02	22.0	0.045	6.1	1.60	0.20	1.0	1.0	53.4							
1530	1	441667	776932	10486	16.1	15.0	2.68	5.4	7.0	3.0	0.10	0.30	0.01	11.0	51.0	47.0	3.40	6.1	21.0	0.08	8.0	0.83	277	1.1	0.03	86.0	0.050	2.6	1.10	0.20	1.0	1.0	51.7				
1540	0	431186	7763367	10631	32.9	38.8	2.44	2.5	2.0	4.0	12.0	0.10	0.25	0.02	21.0	93.0	89.5	4.13	6.3	30.0	0.03	6.0	1.48	394	0.2	0.01	70.0	0.050	4.0	1.20	0.20	1.0	1.0	60.4			
1540	1	431186	7763367	10424	36.0	37.0	1.92	11.7	3.6	1.5	14.0	0.10	0.25	0.03	12.0	214.9	6.3	9.3	32.0	0.03	6.0	2.17	737	0.3	0.01	77.0	0.033	1.8	2.10	0.20	1.0	1.0	74.4				
1550	0	432893	7764792	10411	17.8	15.0	3.72	24.8	1.0	1.5	15.7	0.10	0.43	0.02	45.0	56.0	106.9	11.0	14.0	0.16	5.0	2.49	555	0.3	0.01	64.0	0.40	9.0	1.20	0.20	1.0	1.0	101.7				
1550	1	432893	7764792	10613	17.9	21.7	3.38	6.8	11.4	8.0	12.0	0.10	0.27	0.01	12.0	73.0	7.3	7.8	14.0	0.14	4.0	1.31	374	0.2	0.01	72.0	0.100	11.1	2.60	1.20	1.0	1.0	120.5				
1560	0	430343	7762955	10512	12.5	15.0	2.63	3.4	3.8	4.0	0.26	0.10	0.31	0.04	40.0	11.4	16.6	2.34	6.1	16.0	0.05	11.0	1.72	1355	0.2	0.02	28.0	0.097	2.8	1.30	0.20	1.0	1.0	78.1			
1560	1	430343	7762955	10454	15.0	15.0	2.34	6.1	1.5	1.6	0.10	0.27	0.03	23.0	56.0	51.0	2.69	3.6	14.0	0.05	5.0	1.97	624	0.7	0.01	25.0	0.043	5.0	2.40	1.20	1.0	1.0	96.0				
1570	0	427697	7761006	10537	18.2	10.4	3.48	2.6	2.0	1.5	9.0	0.10	0.21	0.03	12.0	33.0	173.3	4.52	5.0	12.0	0.05	3.0	1.48	394	0.2	0.01	37.0	0.030	3.3	1.20	0.20	1.0	1.0	75.7			
1570	1	427697	7761006	10370	13.8	2.57	3.16	3.0	1.5	2.0	0.21	0.09	0.01	8.0	22.0	133.2	5.04	5.0	12.0	0.05	3.0	1.48	394	0.2	0.01	37.0	0.030	3.3	1.20	0.20	1.0	1.0	83.3				
1580	0	432895	7765985	10375																																	

























B3- and C-horizon samples  
Ringvassøy 1998

Sample	FD	mE34e089	mN34e089	Fine_B	Fine_B	Ag	Ag_B	Al	Al_B	As	As_B	Au	Au_B	B	B_B	Ba	Ba_B	Bi	Bi_B	Ca	Ca_B	Cr	Cr_B	Cu	Cu_B	Fe	Fe_B	Ga	Ga_B	Hg	Hg_B	K	K_B	La	ppm		
	m					ppb		ppm	%	ppm		ppb		ppm		ppm		ppm		ppm		ppm		ppm		ppm		ppb		ppb		%	ppm				
1382	441662	7771691	3816.8	98.5	15.0	2.78	2.59	7.0	3.4	14.7	0.8	1.5	3.0	20.0	13.0	0.10	0.33	0.17	0.01	0.05	11.0	6.0	44.0	32.0	34.4	20.0	2.62	2.58	5.3	7.4	44.0	58.0	0.10	0.05	8.0		
1444	437575	7759194	1443.0	134.3	15.0	4.68	5.78	4.6	2.8	1.2	0.3	1.5	1.5	401.0	381.0	0.10	0.10	0.52	0.07	0.01	0.01	37.0	38.0	287.0	359.0	28.7	19.7	6.33	9.31	14.3	14.2	17.0	1.55	1.51	35.0		
1445	437493	7759410	1394.7	106.4	15.0	41.0	3.05	2.96	3.7	7.9	1.9	1.3	1.5	1.5	368.0	101.0	0.10	0.10	0.53	0.33	0.06	0.01	29.0	20.0	47.0	45.7	112.4	5.15	5.48	8.5	7.2	15.0	27.0	0.96	0.27	3.0	
1448	437496	7760016	1334.9	107.0	15.0	84.0	2.96	2.30	6.1	33.9	2.3	4.4	1.5	9.0	25.0	16.0	0.10	0.30	0.17	0.05	0.08	27.0	16.0	90.0	82.0	79.9	9.0	5.45	5.83	10.7	11.1	19.0	22.0	0.09	0.05	5.0	
1450 D	437501	7760404	1351.4	131.1	91.0	166.0	3.63	3.46	4.3	8.8	14.2	3.4	1.5	14.0	64.0	75.0	0.60	0.30	0.40	0.17	0.11	0.08	47.0	170.0	376.0	174.8	84.4	9.70	10.8	17.7	12.0	0.17	0.24	6.0			
1452	437503	7760805	1769.9	104.2	31.0	67.0	3.75	3.37	22.0	12.9	5.2	5.3	6.0	3.0	34.0	20.0	0.10	0.40	0.29	0.15	0.19	38.0	25.0	102.0	91.0	163.7	115.2	5.65	5.89	8.2	6.8	39.0	95.0	0.10	0.05	8.0	
1453	437510	7761003	1838.2	143.0	151.0	151.0	3.74	3.55	11.1	6.4	1.9	1.4	1.5	3.0	28.0	10.0	0.10	0.28	0.16	0.07	0.05	35.0	20.0	124.0	138.0	175.8	110.4	5.44	7.78	8.0	11.5	35.0	46.0	0.06	0.02	6.0	
1455	437505	7761400	236.8	102.1	15.0	49.0	2.46	2.18	6.0	8.5	3.2	2.0	3.0	1.5	13.0	11.0	0.10	0.19	0.21	0.20	0.24	24.0	21.0	64.0	71.0	50.7	46.8	4.68	4.78	9.5	10.9	24.0	27.0	0.03	0.04	9.0	
1457	437500	7761794	1972.4	144.0	48.0	90.0	3.03	2.93	9.2	12.9	6.1	1.7	1.5	4.0	19.0	8.0	0.20	0.10	0.33	0.15	0.05	0.06	32.0	20.0	134.0	121.0	144.8	99.4	5.07	7.30	5.8	7.8	46.0	76.0	0.05	0.02	8.0
1458	437613	7765008	1838.5	151.2	288.0	78.0	2.76	3.64	53.8	34.5	5.3	10.4	1.5	42.0	13.0	0.10	0.45	0.17	0.14	0.13	76.0	37.0	111.0	115.0	520.7	193.5	6.50	9.83	8.9	7.9	66.0	49.0	0.06	0.03	13.0		
1459	437638	7764798	1841.6	100.0	57.0	70.0	2.57	3.74	103.5	86.5	13.3	4.1	1.5	22.0	15.0	1.30	0.70	0.37	0.22	0.17	0.17	98.0	111.0	89.0	96.0	386.3	293.6	5.43	5.43	6.2	6.4	66.0	116.0	0.03	0.02	11.0	
1460 D	437570	7764590	2232.1	143.3	15.0	15.0	2.30	2.26	18.3	30.4	4.4	0.9	7.0	1.5	12.0	7.0	0.10	0.25	0.13	0.13	0.07	27.0	17.0	79.0	69.0	86.3	96.9	46.9	4.48	6.42	7.4	9.3	13.0	27.0	0.03	0.02	5.0
1460	437570	7764590	1672.2	83.4	539.0	56.0	2.51	2.21	31.8	24.2	5.3	2.1	1.5	8.0	27.0	25.0	0.20	0.10	0.29	0.34	0.14	0.07	47.0	32.0	92.0	78.0	202.3	99.5	5.98	6.9	7.4	11.0	16.0	0.03	0.02	7.0	
1461	437567	7764392	1202.0	37.0	89.0	2.96	3.04	31.3	12.3	7.2	3.0	1.5	7.0	16.0	10.0	0.10	0.20	0.15	0.14	0.10	37.0	20.0	96.0	90.0	171.2	51.7	5.68	6.83	8.9	7.7	15.0	28.0	0.03	0.02	6.0		
1463	437453	7763997	1472.8	78.5	202.0	126.0	3.44	2.35	10.3	10.6	1.5	0.5	1.5	7.0	23.0	29.0	0.10	0.39	0.51	0.06	0.16	44.0	20.0	95.0	76.0	112.6	74.4	6.79	5.33	9.2	6.0	26.0	51.0	0.05	0.02	3.0	
1465	437497	7763582	2631.0	107.9	114.0	224.0	2.35	25.0	16.8	7.7	1.9	6.0	3.0	22.0	7.0	0.10	0.31	0.18	0.06	0.06	18.0	11.0	87.0	81.0	239.4	76.4	3.80	4.10	7.4	8.6	32.0	63.0	0.03	0.02	7.0		
1466	437526	7763405	1394.7	93.2	106.0	207.0	3.76	3.52	6.4	5.7	0.9	0.1	4.0	7.0	83.0	102.0	0.10	0.13	0.09	0.01	0.01	28.0	20.0	252.0	216.0	63.1	51.6	7.17	6.68	14.3	14.1	38.0	27.0	0.22	0.32	14.0	
1468	437479	7763003	2463.1	107.1	158.0	444.0	2.21	4.47	38.1	17.1	5.4	7.8	1.5	1.5	16.0	7.0	0.20	0.48	0.20	3.76	0.54	43.0	13.0	75.0	95.0	432.0	230.7	4.06	4.35	6.1	4.8	75.0	164.0	0.04	0.02	7.0	
1469	437503	7762803	280.9	152.7	37.0	459.0	2.45	3.33	26.0	127.8	5.0	4.5	1.5	6.0	8.0	1.10	0.40	0.20	0.14	0.10	0.16	22.0	21.0	69.0	96.0	251.0	254.5	4.33	6.61	6.5	14.2	30.0	175.0	0.01	0.02	6.0	
1470 D	437500	7762600	3005.6	208.1	166.0	281.0	1.36	6.94	18.3	9.3	29.6	3.1	1.5	12.0	8.0	0.50	0.10	0.38	0.10	0.28	0.10	32.0	14.0	63.0	117.0	178.3	71.4	3.22	6.70	4.9	6.3	11.0	9.6	0.02	0.02	11.0	
1470	437500	7762600	3448.3	284.1	71.0	123.0	1.40	6.00	12.2	7.7	4.2	5.2	1.5	8.0	8.0	0.10	0.33	0.09	0.07	0.08	25.0	13.0	55.0	131.0	102.8	84.5	2.90	8.24	3.6	8.6	25.0	108.0	0.02	0.02	9.0		
1475	431253	7763081	2283.6	91.7	50.0	50.0	2.57	2.51	6.2	3.4	1.6	4.1	6.0	1.5	33.0	13.0	0.10	0.27	0.15	0.02	0.01	31.0	12.0	82.0	65.0	174.6	65.5	4.36	4.00	8.4	7.4	47.0	54.0	0.20	0.12	22.0	
1476	431152	7763018	2551.0	125.5	102.0	64.0	2.24	2.08	5.0	12.7	3.1	1.3	4.0	4.0	34.0	0.10	0.38	0.27	0.01	0.01	17.0	10.0	69.0	45.0	53.8	30.7	3.92	4.92	6.6	9.2	5.0	32.0	21.1	0.15	0.03	30.0	
1478	430644	7768782	1915.7	170.1	15.0	96.0	2.71	2.22	48.9	17.6	3.5	1.8	1.5	13.0	28.0	16.0	0.10	0.25	0.09	0.04	0.03	43.0	12.0	105.0	91.0	158.4	38.8	5.22	8.8	8.8	12.3	39.0	0.02	0.02	4.0		
1479	430448	7766680	6896.6	302.8	36.0	60.0	1.51	2.32	3.1	18.1	6.1	12.9	3.0	1.5	7.0	8.0	0.10	0.12	0.12	0.02	0.01	6.0	11.0	43.0	56.0	48.5	74.5	4.39	8.8	8.0	9.9	5.0	27.0	0.03	0.02	17.0	
1480	430300	7766578	1855.3	114.3	42.0	74.0	2.42	2.49	12.5	18.7	3.9	5.2	1.5	3.0	3.0	63.0	58.0	0.10	0.56	0.54	0.04	0.04	29.0	13.0	96.0	48.0	109.3	167.3	5.39	16.1	24.0	36.6	12.0	24.0	0.17	0.16	7.0
1481	430049	7764941	1876.2	86.5	62.0	105.0	2.49	2.39	20.9	15.4	9.9	1.2	3.0	1.5	31.0	13.0	0.10	0.27	0.11	0.05	0.01	31.0	12.0	82.0	65.0	174.6	65.5	4.36	4.00	8.4	7.4	47.0	54.0	0.20	0.11	0.05	8.0
1482	429850	7768330	89.2	36.0	100.0	3.22	2.80	24.5	20.2	5.1	3.6	1.5	6.0	38.0	15.0	0.10	0.30	0.19	0.02	0.01	29.0	17.0	90.0	70.0	160.7	99.1	5.53	4.93	7.9	6.5	33.0	29.0	0.11	0.05	10.0		
1483	429668	7768321	1655.6	119.9	105.0	164.0	2.85	2.48	59.7	38.6	6.3	3.0	1.5	7.0	38.0	15.0	0.10	0.27	0.11	0.10	0.02	45.0	34.0	90.0	216.4	108.6	6.04	7.24	8.3	8.3	106.2	22.0	0.09	0.05	10.0		
1484	429467	7768188	1379.7	110.2	59.0	15.0	2.42	2.55	52.0	42.5	8.2	5.6	9.0	1.5	20.0	11.0	0.10	0.22	0.12	0.12	0.09	47.0	26.0	88.0	77.0	156.5	125.9	5.32	5.86	8.0	9.9	5.0	27.0	0.05	0.03	17.0	

Sample	FD	mE34e089	mN34e089	Fine	Fine_B	Ag	Ag_B	Al	Al_B	As	As_B	Au	Au_B	B	B_B	Ba	Ba_B	Bi	Bi_B	Ca	Ca_B	Cr	Cr_B	Cu	Cu_B	Fe	Fe_B	Ga	Ga_B	Hg	Hg_B	K	K_B	La	ppm		
m				ppb	%	ppm	ppm	ppm	ppm	ppm	ppm	ppb	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppb	%	ppm	ppb	%	ppm					
1382	441662	7771691	3816.8	98.5	15.0	2.78	2.59	7.0	3.4	14.7	0.8	1.5	3.0	20.0	13.0	0.10	0.33	0.17	0.01	0.05	11.0	6.0	44.0	32.0	34.4	20.0	2.62	2.58	5.3	7.4	44.0	58.0	0.10	0.05	8.0		
1444	437575	7759194	1443.0	134.3	15.0	4.68	5.78	4.6	2.8	1.2	0.3	1.5	1.5	401.0	381.0	0.10	0.52	0.07	0.01	0.01	37.0	38.0	287.0	359.0	28.7	19.7	6.33	9.31	14.3	14.2	17.0	1.55	1.51	35.0			
1445	437493	7759410	1394.17	106.4	15.0	41.0	3.05	2.96	3.7	7.9	1.9	1.3	1.5	368.0	101.0	0.10	0.53	0.33	0.06	0.01	29.0	20.0	47.0	45.7	112.4	5.15	5.48	8.5	7.2	15.0	27.0	0.96	0.27	3.0			
1448	437496	7760016	1334.9	107.0	15.0	84.0	2.96	2.30	6.1	33.9	2.3	4.4	1.5	9.0	25.0	16.0	0.10	0.30	0.17	0.05	0.08	27.0	16.0	90.0	82.0	79.9	9.0	5.45	5.83	10.7	11.1	19.0	22.0	0.09	0.05	5.0	
1450 D	437501	7760404	1351.4	131.1	91.0	166.0	3.63	3.46	4.3	8.8	14.2	3.4	1.5	14.0	64.0	75.0	0.60	0.30	0.40	0.11	0.08	47.0	170.0	376.0	174.8	84.4	9.7	10.8	17.7	12.0	0.17	0.24	6.0				
1452	437503	7760805	1769.9	104.2	31.0	67.0	3.75	3.37	22.0	12.9	5.2	5.3	6.0	3.0	34.0	20.0	0.10	0.40	0.29	0.15	0.19	40.0	25.0	102.0	91.0	63.7	115.2	5.65	5.89	8.2	6.8	39.0	95.0	0.10	0.05	8.0	
1453	437510	7761003	1838.2	143.0	151.0	151.0	3.74	3.55	11.1	6.4	1.9	1.4	1.5	3.0	28.0	10.0	0.10	0.28	0.16	0.07	0.05	35.0	20.0	124.0	138.0	75.8	110.4	5.44	7.78	8.0	11.5	35.0	46.0	0.06	0.02	6.0	
1455	437505	7761400	236.8	102.1	15.0	49.0	2.46	2.18	6.0	8.5	3.2	2.0	3.0	1.5	13.0	11.0	0.10	0.19	0.21	0.20	0.24	24.0	21.0	64.0	71.0	50.7	46.8	4.68	4.78	9.5	10.9	24.0	27.0	0.03	0.04	9.0	
1457	437500	7761794	1972.4	144.0	48.0	90.0	3.03	2.93	9.2	12.9	6.1	1.7	1.5	4.0	19.0	8.0	0.20	0.10	0.33	0.15	0.05	32.0	20.0	134.0	121.0	144.8	99.4	5.07	7.30	5.8	7.8	46.0	76.0	0.05	0.02	8.0	
1458	437613	7765008	1838.5	151.2	288.0	78.0	2.76	3.64	53.8	34.5	5.3	10.4	1.5	42.0	13.0	0.10	0.45	0.17	0.14	0.13	76.0	37.0	111.0	115.0	520.7	193.5	6.50	9.83	8.9	7.9	66.0	49.0	0.06	0.03	13.0		
1459	437638	7764798	1841.6	100.0	57.0	70.0	2.57	3.74	103.5	86.5	13.3	4.1	1.5	22.0	15.0	1.30	0.70	0.37	0.22	0.17	1.17	98.0	111.0	89.0	96.0	386.3	293.6	5.43	5.43	6.2	6.4	66.0	116.0	0.03	0.02	11.0	
1460 D	437570	7764590	2232.1	143.3	15.0	15.0	2.30	2.26	18.3	30.4	4.4	0.9	7.0	1.5	12.0	7.0	0.10	0.25	0.13	0.13	0.07	27.0	17.0	79.0	69.0	86.3	46.9	4.48	6.42	7.4	9.3	13.0	27.0	0.03	0.02	5.0	
1460	437570	7764590	1672.2	83.4	539.0	56.0	2.51	2.21	31.8	24.2	5.3	2.1	1.5	8.0	27.0	25.0	0.20	0.10	0.29	0.34	0.14	0.07	47.0	32.0	92.0	78.0	202.3	99.5	5.98	6.9	7.4	11.0	16.0	0.03	0.02	7.0	
1461	437567	7764392	1202.0	37.0	89.0	2.96	3.04	31.3	12.3	7.2	3.0	1.5	7.0	16.0	10.0	0.10	0.20	0.15	0.14	0.10	37.0	20.0	96.0	90.0	171.2	51.7	5.68	6.83	8.9	7.7	15.0	28.0	0.03	0.02	6.0		
1463	437453	7763997	1472.8	78.5	220.0	126.0	3.44	2.35	10.3	10.6	1.5	0.5	1.5	7.0	23.0	20.0	0.10	0.39	0.51	0.06	0.16	44.0	20.0	95.0	76.0	112.6	74.4	6.79	5.33	9.2	6.0	26.0	51.0	0.05	0.02	3.0	
1465	437497	7763582	2631.0	107.9	114.0	224.0	2.35	25.0	16.8	7.7	1.9	6.0	3.0	22.0	7.0	0.10	0.31	0.18	0.06	0.06	18.0	11.0	87.0	81.0	239.4	76.4	3.80	4.10	7.4	8.6	32.0	63.0	0.03	0.02	7.0		
1466	437526	7763405	1394.7	93.2	106.0	207.0	3.76	3.52	6.4	5.7	0.9	0.1	4.0	7.0	83.0	102.0	0.10	0.13	0.09	0.01	0.01	28.0	20.0	252.0	216.0	63.1	51.6	7.17	6.68	14.3	14.1	38.0	27.0	0.22	0.32	14.0	
1468	437479	7763003	2463.1	107.1	158.0	444.0	2.21	4.47	38.1	17.1	5.4	7.8	1.5	1.5	16.0	7.0	0.20	0.48	0.20	3.76	0.54	43.0	13.0	75.0	95.0	432.0	230.7	4.06	4.35	6.1	4.8	75.0	164.0	0.04	0.02	7.0	
1469	437503	7762803	280.9.5	152.7	37.0	459.0	2.45	3.33	26.0	127.8	5.0	4.5	1.5	6.0	8.0	1.10	0.40	0.20	0.14	0.10	16.0	22.0	21.0	69.0	96.0	251.0	284.5	4.33	6.61	6.5	14.2	30.0	175.0	0.01	0.02	6.0	
1470 D	437500	7762600	3005.6	208.1	166.0	281.0	1.36	6.94	18.3	9.3	29.6	3.1	1.5	12.0	8.0	0.50	0.10	0.38	0.10	0.28	14.0	12.0	63.0	117.0	178.3	71.4	3.22	6.70	4.9	6.3	11.0	9.6	0.02	0.02	11.0		
1470	437500	7762600	3448.3	284.1	71.0	123.0	1.40	6.00	12.2	7.7	4.2	5.2	1.5	8.0	8.0	0.10	0.33	0.09	0.07	0.08	25.0	13.0	55.0	131.0	102.8	84.5	2.90	8.24	3.6	8.6	25.0	108.0	0.02	0.02	9.0		
1475	431253	7763081	2283.6	91.7	50.0	50.0	2.57	2.51	6.2	3.4	1.6	4.1	6.0	1.5	33.0	13.0	0.10	0.27	0.15	0.02	0.01	31.0	12.0	82.0	65.0	174.6	65.5	4.36	4.00	8.4	7.4	47.0	54.0	0.20	0.12	22.0	
1476	431152	7763018	2551.0	125.5	102.0	64.0	2.24	2.08	5.0	12.7	3.1	1.3	4.0	4.0	34.0	0.10	0.38	0.27	0.01	0.01	17.0	10.0	69.0	45.0	53.8	30.7	3.92	4.92	6.6	9.2	5.0	32.0	21.15	30.0			
1478	430644	7768782	1915.7	170.1	15.0	96.0	2.71	2.22	48.9	17.6	3.5	1.8	1.5	13.0	28.0	16.0	0.10	0.25	0.09	0.04	0.03	43.0	12.0	105.0	91.0	158.4	38.8	5.22	8.8	8.5	12.3	39.0	0.02	0.02	7.0		
1479	430448	7766860	6896.6	302.8	36.0	60.0	1.51	2.32	3.1	18.1	6.1	12.9	3.0	1.5	7.0	8.0	0.10	0.12	0.12	0.02	0.01	6.0	11.0	43.0	56.0	48.5	74.5	4.39	8.8	8.0	9.9	5.0	27.0	0.03	0.02	17.0	
1480	430300	7766578	1855.3	114.3	42.0	74.0	2.42	2.49	12.5	18.7	3.9	5.2	1.5	3.0	3.0	63.0	58.0	0.10	0.56	0.54	0.04	0.04	29.0	13.0	96.0	48.0	109.3	167.3	5.39	16.1	24.0	36.6	12.0	24.0	0.17	0.16	7.0
1481	430049	7764941	1876.2	86.5	62.0	105.0	2.49	2.39	20.9	15.4	9.9	1.2	3.0	1.5	31.0	13.0	0.10	0.27	0.11	0.05	0.01	31.0	12.0	82.0	65.0	174.6	65.5	4.36	4.00	8.4	7.4	47.0	54.0	0.20	0.11	8.0	
1482	429850	7768330	89.2	36.0	100.0	3.22	2.80	24.5	20.2	5.1	3.6	1.5	6.0	38.0	15.0	0.10	0.30	0.19	0.02	0.01	29.0	17.0	90.0	70.0	160.7	99.1	5.53	4.93	7.9	6.5	33.0	29.0	0.11	0.05	10.0		
1483	429668	7768321	1655.6	119.9	105.0	164.0	2.85	2.48	59.7	38.6	6.3	3.0	1.5	7.0	38.0	15.0	0.10	0.27	0.11	0.10	0.02	45.0	34.0	90.0	216.4	108.6	6.04	7.24	8.3	8.3	106.2	22.0	0.09	0.05	10.0		
1484	429467	7768188	1879.7	110.2	59.0	15.0	2.42	2.55	52.0	42.5	8.2	5.6	9.0	1.5	20.0	11.0	0.10	0.22	0.12	0.12	0.09	47.0	26.0	88.0	77.0	156.5	125.9	5.32	5.86	8.0	9.9	5.0	27.0	0.05	0.03	17.0	
1485	429296	7766115	1869.2	97.0	92																																



## C-horizon Ringvassøy 1988

Sample	FDnE34eu689	Fine	As	Al	Ba	B	Au	Cr	Cu	Fe	Ga	Hg	K	La	Mg	Mn	Ni	P	Pb	Sb	Se	Te	Th	Ti	U	V	W	Zn									
	m	%	ppb	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm									
1381	441638	7771734	10.5	15.0	2.26	10.3	1.5	5.0	33.0	0.10	0.38	0.03	22.0	56.0	102.8	3.92	8.6	18.0	0.17	13.0	0.16	60.1	0.02	38.0	0.15	2.5	68.0	1.0									
1382	441662	7771691	9.4	15.0	2.78	7.0	14.7	1.5	19.0	0.10	0.33	0.01	11.0	44.0	34.4	2.62	5.3	44.0	0.10	8.0	0.77	262	0.02	24.0	0.075	7.1	0.40	1.40	25.0	1.0							
1383	441700	7771562	42.0	88.0	1.68	23.8	2.2	1.5	19.0	0.10	0.32	0.03	11.0	43.0	32.5	2.75	10.9	13.0	0.07	5.0	1.01	242	2.0	0.02	27.0	0.007	8.2	0.40	0.60	36.0	0.1						
1384	438607	7765058	31.1	15.0	3.02	42.7	16.8	1.5	20.0	0.10	0.43	0.14	58.0	106.0	212.4	5.66	8.9	16.0	0.05	6.0	0.04	954	0.02	240.0	0.075	24.0	0.075	7.1	0.40	1.40	25.0	1.0					
1385	438688	7765113	18.0	15.0	1.35	67.5	2.6	1.5	19.0	0.10	0.37	0.14	63.0	59.0	148.5	3.46	4.7	5.0	0.09	8.0	0.83	1419	0.02	38.0	0.109	2.8	0.90	0.40	12.0	0.1							
1386	438690	7765162	43.5	15.0	1.27	23.2	5.9	1.5	9.0	0.10	0.37	0.06	35.0	53.0	112.4	2.96	3.9	14.0	0.02	6.0	0.87	762	0.02	34.0	0.094	1.6	0.40	0.15	10.0	0.1							
1387	441567	7766442	31.9	53.0	3.07	11.0	4.3	1.5	24.0	0.10	0.31	0.12	41.0	89.0	142.7	6.84	10.7	28.0	0.10	6.0	116.0	118.6	0.01	2.8	0.80	15.5	0.01	1.0	0.07	2.5	163.0	1.0					
1388	441348	7765044	22.3	52.0	2.27	31.9	10.2	1.0	30.0	0.20	0.37	0.23	53.0	82.0	245.0	5.63	8.0	28.0	0.08	8.0	1.72	1615	0.8	0.02	54.0	0.135	3.2	1.20	0.15	10.0	0.1						
1389	441375	7765033	18.3	60.0	3.41	24.2	9.6	1.5	63.0	0.70	0.43	0.24	72.0	108.0	243.9	7.93	11.1	44.0	0.12	6.0	2.84	1876	0.01	81.0	1.40	3.4	0.60	0.15	10.0	0.2	2.5	137.0	1.0				
1390	427400	7768150	44.8	54.0	1.08	23.2	2.7	1.5	13.0	0.10	0.33	0.02	22.0	44.0	102.9	2.61	4.3	18.0	0.03	6.0	0.86	816	0.1	32.0	0.077	1.6	0.30	0.15	8.0	0.1	0.05	2.5	61.0	1.0			
1391	427400	7768050	37.1	54.0	1.29	44.2	5.7	1.5	10.0	0.10	0.16	0.03	12.0	83.0	22.4	4.47	12.3	31.0	0.05	4.0	1.14	236	14.6	0.02	28.0	0.018	3.4	0.40	0.40	6.0	0.1	0.13	2.5	130.0	1.0		
1392	427400	7768056	35.0	54.0	2.01	19.4	2.1	1.5	15.0	0.10	0.18	0.01	12.0	78.0	31.3	3.57	8.7	15.0	0.07	5.0	1.13	224	4.3	0.02	31.0	0.020	2.2	0.30	0.40	6.0	0.1	0.12	1.5	213.0	1.0		
1401	443389	7764004	26.0	54.0	4.41	20.6	4.4	1.5	43.0	0.10	0.14	0.01	55.0	116.0	174.4	10.06	12.2	24.0	0.09	5.0	2.59	1755	0.1	0.01	84.0	0.052	1.5	10.60	0.90	5.0	2.0	15.0	1.0				
1402	443201	7764000	18.5	54.0	2.09	7.2	1.0	1.5	6.0	0.10	0.04	0.01	19.0	788.0	7.2	3.54	10.4	50.0	0.03	1.0	2.54	348	0.1	0.01	159.0	0.15	2.0	1.50	0.15	10.0	0.1						
1403	443001	7764000	24.1	53.0	3.00	96.5	5.1	1.5	10.0	0.10	0.03	0.09	47.0	128.0	75.0	9.45	8.8	37.0	0.02	7.0	1.48	2190	0.01	93.0	0.046	1.7	14.20	1.30	2.0	0.3	1.0	0.05	1.0				
1404	442801	7764001	42.5	54.0	2.61	44.7	2.7	1.5	29.0	0.10	0.19	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.68	636	1.3	0.01	94.0	0.070	2.2	4.10	1.10	4.0	0.1	0.05	2.5	61.0	1.0		
1405	442898	7764000	41.8	41.0	2.51	2.6	2.0	4.0	5.0	0.10	0.02	0.01	59.0	52.5	4.98	9.9	14.0	0.01	4.0	1.48	53.0	0.2	0.01	71.0	0.041	2.3	0.50	0.70	1.0	0.1	0.02	2.5	128.0	1.0			
1406	442899	7764004	30.0	91.0	2.23	9.8	2.3	1.0	2.0	0.10	0.01	0.01	60.0	72.0	24.9	5.80	13.2	18.0	0.01	3.0	1.06	224	0.5	0.01	44.0	0.031	1.1	0.80	0.60	1.0	0.1	0.02	2.5	143.0	1.0		
1407	442200	7763989	16.8	64.0	4.51	18.6	4.4	1.5	7.0	0.10	0.16	0.09	52.0	53.0	129.3	12.02	21.0	25.0	0.01	8.0	2.65	1732	0.3	0.01	48.0	0.092	2.5	9.70	0.60	5.0	1.0	0.03	2.5	336.0	1.0		
1408	441996	7763996	40.3	15.0	3.61	54.1	4.1	1.5	49.0	0.10	0.15	0.08	47.0	142.0	222.7	8.02	12.0	28.0	0.01	12.0	2.57	1756	0.3	0.01	110.0	0.069	1.8	7.40	0.90	6.0	0.2	1.0	0.09	1.0	161.0	1.0	
1409	441799	7764002	14.4	54.0	3.89	171.8	1.8	6.0	28.0	0.10	0.09	0.24	73.0	111.0	233.8	12.70	16.6	34.0	0.02	6.0	1.99	4471	0.5	0.01	121.0	0.082	3.1	28.60	1.70	4.0	0.2	1.0	0.03	1.0	143.7	1.0	
1410	D	441587	7764002	24.5	36.0	3.89	33.3	3.0	5.0	23.0	0.10	0.20	0.07	46.0	141.0	222.9	9.26	10.3	63.0	0.04	6.0	2.50	2291	0.3	0.01	94.0	0.070	4.0	13.20	0.90	4.0	0.1	0.04	2.5	161.0	1.0	
1410	D	441587	7764002	22.0	46.4	5.1	40.0	5.1	1.5	14.0	0.50	0.08	0.11	52.0	59.0	141.0	2.51	5.5	17.50	0.11	8.0	2.50	1889	0.6	0.01	74.0	0.065	1.9	11.50	1.90	4.0	0.1	0.03	2.5	193.0	1.0	
1411	441400	7764003	18.8	15.0	3.92	26.5	0.4	6.0	10.0	0.10	0.11	0.04	39.0	11.0	160.3	7.65	9.1	17.0	0.02	4.0	2.31	1645	0.4	0.01	74.0	0.068	1.4	2.70	0.90	4.0	0.1	0.03	2.5	156.0	1.0		
1412	441198	7763989	18.7	15.0	3.98	29.9	5.2	1.5	31.0	0.10	0.16	0.12	44.0	146.0	226.6	7.60	11.8	23.0	0.02	6.0	1.91	2848	1.8	0.01	94.0	0.048	2.5	9.70	0.60	5.0	1.0	0.04	2.5	153.0	1.0		
1413	441000	7764000	21.9	57.0	4.49	11.5	3.1	1.5	25.0	0.10	0.20	0.08	37.0	133.0	158.3	9.05	13.1	24.0	0.03	4.0	3.48	2629	0.5	0.01	94.0	0.048	2.5	9.70	0.60	5.0	1.0	0.04	2.5	211.0	1.0		
1414	440799	7763989	19.6	15.0	3.38	37.9	0.1	5.0	28.0	0.10	0.18	0.07	38.0	100.0	138.6	7.36	8.4	5.0	0.01	4.0	1.92	1363	0.1	0.01	67.0	0.042	2.4	3.10	0.60	7.0	0.1	0.03	2.5	162.0	1.0		
1415	440599	7764005	25.6	15.0	3.88	129.1	0.7	1.5	64.0	0.10	0.38	0.11	30.0	94.0	106.4	8.55	10.9	55.0	0.17	4.0	7.79	192	0.01	59.0	0.059	2.7	3.90	0.90	4.0	0.1	0.07	2.5	226.0	1.0			
1416	440401	7764002	20.5	40.0	2.81	13.2	4.0	9.0	86.0	0.10	0.28	0.39	72.0	159.0	239.6	8.66	10.9	50.0	0.16	4.0	1.87	1303	0.01	45.0	0.036	4.2	10.00	0.40	6.0	0.1	0.09	2.5	231.0	1.0			
1417	440212	7764006	17.3	125.0	4.90	366.9	9.0	1.5	80.0	0.10	0.22	0.07	38.0	109.0	90.5	8.65	11.8	26.0	0.03	5.0	2.62	826	0.01	67.0	0.040	2.3	3.20	0.40	9.0	0.1	0.04	2.5	263.0	1.0			
1418	440002	7763989	13.1	68.0	4.99	27.7	1.9	14.0	1.4	12.0	0.10	0.22	0.08	44.0	146.0	149.9	14.9	19.3	9.4	42.0	0.02	6.0	1.91	2848	1.8	0.01	66.0	0.066	3.4	5.80	2.80	4.0	0.2	0.04	2.5	156.0	2.0
1419	441195	7763987	25.5	93.0	4.25	30.1	2.4	13.0	2.4	17.0	0.10	0.23	0.01	40.0	128.0	114.7	9.13	12.8	27.0	0.03	4.0	2.93	984	0.7	0.01	77.0	0.054	0.9	1.70	0.15	7.0	0.1	0.05	2.5	197.0	2.0	
1420	D	439793	7764000	32.9	52.0	3.66	22.3	2.2	1.5	12.0	0.10	0.12	0.08	47.0	121.0	141.8	7.41	9.7	6.0	0.06	7.0</																

## C-horizon Ringvassøy 1988

Sample	FDnE34eu689	Fine	As	Al	Ba	Bi	Ca	Cd	Cr	Cu	Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	P	Pb	Sb	Se	Si	Te	Th	Ti	U	V	Zn										
1381	441638	7771734	10.5	15.0	2.26	10.3	3.0	0.10	0.38	0.03	22.0	106.0	3.92	8.6	18.0	0.17	13.0	0.16	60.1	0.02	38.0	0.15	3.0	0.09	0.1	2.5	68.0	1.0	74.1											
1382	441662	7771691	9.4	15.0	2.78	7.0	14.7	1.5	19.0	0.10	0.33	0.01	11.0	44.0	34.4	2.62	5.3	44.0	0.10	8.0	0.77	262	0.02	24.0	0.075	7.1	0.40	1.40	25.0	1.0	49.1									
1383	441700	7771562	42.0	88.0	1.68	23.8	2.2	1.5	19.0	0.10	0.32	0.03	11.0	43.0	32.5	2.75	10.9	13.0	0.07	5.0	1.01	242	2.0	0.02	27.0	0.007	8.2	0.40	0.60	36.0	0.1	1.0	1.8	0.3	2.5	62.0	1.0	52.9		
1384	438807	7765058	31.1	15.0	3.02	42.7	16.8	1.5	20.0	0.10	0.43	0.14	58.0	106.0	212.4	5.6	8.9	16.0	0.05	6.0	0.04	78.0	0.066	2.8	0.70	0.90	15.0	0.1	0.09	0.2	6.0	12.0	1.0	91.0						
1385	438888	7765113	18.0	15.0	1.35	67.5	2.6	1.5	19.0	0.10	0.37	0.14	63.0	59.0	148.5	3.46	4.7	5.0	0.09	8.0	0.83	1419	0.02	38.0	0.109	2.8	0.90	0.40	12.0	0.1	1.0	0.06	0.3	2.5	101.0	1.0	55.7			
1386	438890	7765162	43.5	15.0	1.27	23.2	5.9	1.5	9.0	0.10	0.37	0.06	35.0	53.0	112.4	2.96	3.9	14.0	0.02	6.0	0.87	762	0.02	34.0	0.094	1.6	0.40	0.15	10.0	0.1	1.0	0.05	0.1	1.0	130.0	0.0	39.8			
1387	441567	7766462	31.9	53.0	3.07	11.0	4.3	1.5	24.0	0.10	0.31	0.23	41.0	89.0	142.7	6.84	10.7	28.0	0.10	6.0	116.0	118.6	0.01	2.3	0.80	15.5	0.01	1.0	0.07	0.2	1.0	2.5	163.0	1.0	108.5					
1388	441348	7765044	22.3	52.0	2.37	31.9	10.2	1.0	30.0	0.20	0.37	0.23	53.0	82.0	245.0	5.63	8.0	28.0	0.08	8.0	1.72	1615	0.8	0.02	54.0	0.135	3.2	1.20	0.15	10.0	0.1	2.0	0.06	0.2	2.5	137.0	2.0	101.6		
1389	441375	7760333	18.3	60.0	3.41	24.2	9.6	1.5	63.0	0.70	0.43	0.24	72.0	109.0	243.9	7.93	11.1	44.0	0.12	6.0	2.84	1876	0.01	81.0	1.40	3.4	0.60	0.15	10.0	0.2	1.0	0.08	0.2	2.5	173.0	1.0	134.7			
1390	427400	7768150	44.8	54.0	1.08	23.2	2.7	1.5	13.0	0.10	0.33	0.02	22.0	44.0	102.9	2.61	4.3	18.0	0.03	6.0	0.86	816	0.02	32.0	0.077	1.6	0.30	0.15	8.0	0.1	0.05	0.1	2.5	61.0	1.0	30.2				
1391	427400	7769050	37.1	50.0	1.29	44.2	5.7	1.5	10.0	0.10	0.16	0.03	12.0	83.0	22.4	4.47	12.3	31.0	0.05	4.0	1.14	236	14.6	0.02	28.0	0.018	3.4	0.40	0.2	6.0	0.5	1.0	0.13	0.2	1.0	130.0	1.0	48.2		
1392	427400	7768956	35.0	51.0	2.01	19.4	2.1	1.5	15.0	0.10	0.18	0.01	12.0	78.0	31.3	3.57	8.7	15.0	0.07	5.0	1.13	224	4.3	0.02	31.0	0.020	2.2	0.30	0.40	6.0	0.1	0.12	0.1	2.5	88.0	1.0	48.9			
1401	443399	7764004	26.5	52.0	4.41	206.3	4.4	1.5	43.0	0.10	0.14	0.01	55.0	116.0	174.4	10.6	12.2	24.0	0.09	5.0	2.59	1755	0.01	15.0	0.052	1.5	10.60	0.90	0.2	1.0	0.16	0.0	9.0	213.0	3.0	152.0				
1402	443201	7764000	18.5	50.0	2.09	7.2	1.0	1.5	6.0	0.10	0.04	0.01	19.0	788.0	7.2	3.54	10.4	5.0	0.03	1.0	2.54	348	0.1	0.01	159.0	0.015	2.0	1.50	0.15	1.0	0.2	2.5	72.0	1.0	47.9					
1403	443001	7764000	24.1	33.0	3.00	96.5	5.1	1.5	10.0	0.10	0.03	0.09	47.0	128.0	75.0	9.45	8.8	37.0	0.02	7.0	1.48	2190	0.01	93.0	0.046	1.7	14.20	1.30	2.0	0.3	1.0	0.05	0.1	2.5	114.0	1.0	84.8			
1404	442800	7764001	42.6	51.0	2.61	24.7	2.7	1.5	29.0	0.10	0.33	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.68	636	1.3	0.01	71.0	0.056	2.2	1.10	0.10	4.0	0.1	0.05	0.1	2.5	61.0	1.0	80.2			
1405	442898	7764000	41.8	41.0	2.51	2.6	2.0	4.0	5.0	0.10	0.02	0.01	59.0	52.5	4.98	9.9	14.0	0.01	4.0	1.48	538	0.2	0.01	21.0	0.041	2.3	0.50	0.70	1.0	0.1	0.02	0.1	2.5	128.0	1.0	57.5				
1406	442899	7764004	30.0	91.0	2.23	9.8	2.3	1.5	24.0	0.10	0.01	0.01	16.0	72.0	24.9	5.80	13.2	18.0	0.01	3.0	1.06	224	0.5	0.01	44.0	0.031	1.1	0.80	0.60	1.0	0.1	0.12	0.1	2.5	143.0	1.0	56.9			
1407	442200	7763989	16.8	44.0	4.51	18.6	4.4	1.5	18.0	0.10	0.16	0.09	52.0	53.0	129.3	12.02	21.0	25.0	0.02	8.0	2.65	1732	0.3	0.01	48.0	0.092	2.5	9.70	0.60	5.0	0.1	0.03	0.1	2.5	336.0	1.0	168.0			
1408	441996	7763986	40.3	15.0	3.61	54.1	4.1	1.5	49.0	0.10	0.15	0.08	47.0	142.0	222.7	8.02	12.0	28.0	0.01	12.0	2.57	1756	0.3	0.01	110.0	0.069	1.8	7.40	0.90	6.0	0.1	0.09	0.1	2.5	161.0	1.0	121.1			
1409	441799	7764002	14.4	54.0	3.89	171.8	1.8	6.0	28.0	0.10	0.09	0.24	73.0	111.0	233.8	12.70	16.6	34.0	0.02	6.0	1.99	4471	0.5	0.01	121.0	0.082	3.1	28.60	1.70	4.0	0.2	1.0	0.03	0.1	2.5	139.0	1.0	143.7		
1410	D	441587	7764002	24.5	36.0	3.89	33.3	3.0	5.0	23.0	0.10	0.30	0.01	121.0	229.1	133.0	6.16	7.5	19.0	0.11	6.0	2.50	2291	0.3	0.01	94.0	0.070	4.0	13.20	0.50	4.0	0.1	0.04	0.1	2.5	161.0	1.0	113.4		
1410	D	441587	7764002	22.0	46.4	5.1	40.0	2.81	11.2	4.0	9.0	86.0	0.10	0.28	0.39	72.0	175.0	181.0	8.37	12.5	57.0	0.02	4.0	2.50	1889	0.6	0.01	145.0	0.065	1.9	11.50	1.90	4.0	0.1	0.03	0.3	2.5	193.0	1.0	98.7
1411	441400	7764003	18.8	15.0	3.92	26.5	0.4	6.0	10.0	0.10	0.14	0.04	39.0	11.0	160.3	7.65	9.1	27.0	0.02	4.0	2.31	1645	0.4	0.01	74.0	0.068	1.4	2.70	0.90	4.0	0.1	0.03	0.1	2.5	156.0	1.0	102.2			
1412	441402	7764006	17.3	125.0	4.90	366.9	1.4	1.2	18.0	0.10	0.22	0.07	38.0	113.0	168.0	415.9	11.12	17.8	70.0	0.07	8.0	3.38	2286	0.7	0.01	126.0	0.052	3.4	7.40	0.80	9.0	0.2	0.04	0.2	2.5	263.0	1.0	151.3		
1413	440002	7763986	13.1	68.0	4.99	237.7	1.9	14.0	52.2	0.10	0.22	0.08	44.0	146.0	446.0	94.9	9.43	9.4	42.0	0.02	6.0	1.91	2848	1.8	0.01	94.0	0.048	5.8	5.80	2.80	4.0	0.2	0.04	0.2	2.5	156.0	2.0	111.1		
1414	441495	7764000	21.9	57.0	3.98	73.5	3.1	1.5	24.0	0.10	0.12	0.08	47.0	153.0	183.8	87.4	7.2	52.0	0.05	7.0	1.77	1992	0.7	0.01	66.0	0.069	2.8	4.00	1.50	5.0	0.1	0.04	0.2	2.5	143.0	2.0	137.3			
1415	440589	7763988	25.6	15.0	3.88	129.1	0.7	1.5	64.0	0.10	0.38	0.11	30.0	94.0	106.4	8.55	10.9	55.0	0.17	4.0	1.79	2159	0.9	0.01	59.0	0.059	2.7	5.80	1.80	4.0	0.1	0.07	0.1	2.5	122.0	1.0	147.0			
1416	440401	7764007	20.5	40.0	2.81	112.2	4.0	9.0	86.0	0.10	0.28	0.39	57.0	110.0	229.6	86.6	10.9	53.0	0.11	5.0	1.65	1042	0.3	0.01	45.0	0.036	4.2	10.00	4.0	6.0	0.1	0.09	0.2	2.5	153.0	1.0	108.3			
1417	440212	7764006	15.6	89.0	4.37	92.1	12.5	1.5	21.0	0.10	0.25	0.05	147.0	135.0	150.5	42.0	0.03	5.0	2.82	1513	0.4	0.01	54.0	0.036	6.0	5.60	1.10	5.0	0.1	0.13	0.1	2.5	180.0	1.0	118.7					
1422	444004	7763987	51.0	54.0	4.05	139.0	1.4	12.0	18.0	0.10	0.22	0.07	38.0	109.0	90.5	86.5	11.8	26.0	0.03	5.0	2.62	826	0.6	0.01	67.0	0.040</														

## C-horizon Ringvassøy 1988

Sample	FDnE34eu89	mN34eu89	Fine	Ag	Al	As	Au	B	Ba	Bi	Ca	Cr	Cu	Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	P	Pb	Sb	Se	Si	Te	Th	Ti	U	V	W	Zn						
	m	%	ppm	ppb	%	ppm	ppb	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm	ppm								
1381	441638	7771734	10.5	15.0	2.26	10.3	1.5	5.0	33.0	0.10	0.38	0.03	22.0	56.0	102.8	3.92	8.6	18.0	0.17	13.0	0.17	31.0	0.1	0.02	38.0	0.086	9.7	0.40	1.40	0.2	2.5	68.0	1.0	74.1						
1382	441662	7771691	9.4	15.0	2.78	7.0	14.7	1.5	19.0	0.10	0.33	0.01	11.0	44.0	34.4	2.62	5.3	44.0	0.10	0.07	26.2	0.06	0.02	24.0	0.075	7.1	0.40	1.40	25.0	0.1	2.5	38.0	1.0	49.1						
1383	441700	7771562	42.0	88.0	1.68	23.8	2.2	1.5	19.0	0.10	0.32	0.03	11.0	43.0	32.5	2.75	10.9	13.0	0.07	5.0	1.01	242	2.0	0.02	27.0	0.007	8.2	0.40	1.60	36.0	0.1	1.0	1.8	0.3	2.5	62.0	1.0	52.9		
1384	438807	7765058	31.1	15.0	3.02	42.7	16.8	1.5	20.0	0.10	0.43	0.14	58.0	106.0	212.4	5.6	8.9	16.0	0.05	1.6	0.04	24.0	0.066	2.8	0.70	1.90	15.0	0.1	0.02	6.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	91.0		
1385	438888	7765113	18.0	15.0	1.35	67.5	2.6	1.5	19.0	0.10	0.37	0.14	63.0	59.0	148.5	3.46	4.7	5.0	0.09	8.0	0.83	1419	0.02	38.0	0.109	28.8	0.90	0.40	12.0	0.1	1.0	0.06	0.3	2.5	101.0	1.0	55.7			
1386	438890	7765162	43.5	15.0	1.27	23.2	5.9	1.5	9.0	0.10	0.37	0.06	35.0	53.0	112.4	2.96	3.9	14.0	0.02	6.0	0.87	762	0.02	34.0	0.094	1.6	0.40	0.15	10.0	0.1	1.0	0.05	1.0	1.0	1.0	1.0	1.0	1.0	1.0	39.8
1387	441567	7766462	31.9	53.0	3.07	11.0	4.3	1.5	24.0	0.10	0.31	0.12	41.0	89.0	142.7	6.84	10.7	28.0	0.10	6.0	116.0	12.0	0.02	118.6	0.01	2.3	0.80	1.15	8.0	0.01	1.0	0.07	1.0	2.5	163.0	1.0	108.5			
1388	441348	7765044	22.3	52.0	2.70	31.9	10.2	1.0	30.0	0.20	0.37	0.23	53.0	82.0	245.0	5.63	8.0	28.0	0.08	8.0	1.72	1615	0.8	0.02	54.0	0.135	3.2	1.20	0.15	10.0	0.1	2.0	0.06	0.2	2.5	137.0	2.0	101.6		
1389	441375	7760333	18.3	60.0	3.41	24.2	9.6	1.5	63.0	0.70	0.43	0.24	72.0	109.0	243.9	7.93	11.1	44.0	0.12	6.0	2.84	1876	0.2	0.01	81.0	1.40	3.4	0.60	0.15	10.0	0.2	1.0	2.5	173.0	1.0	134.7				
1390	427400	7768150	44.8	54.0	1.08	23.2	2.7	1.5	13.0	0.10	0.33	0.02	22.0	44.0	102.9	2.61	4.3	18.0	0.03	6.0	1.69	816	1.0	0.02	32.0	0.077	1.6	0.30	0.15	8.0	0.1	0.05	0.1	2.5	61.0	1.0	30.2			
1391	427400	7769050	37.1	50.0	1.29	44.2	5.7	1.5	10.0	0.10	0.16	0.03	12.0	83.0	22.4	4.47	12.3	31.0	0.05	4.0	1.14	236	14.6	0.02	28.0	0.018	3.4	0.40	0.2	6.0	0.1	0.13	0.0	2.5	130.0	1.0	48.2			
1392	427400	7768956	35.0	51.0	2.01	19.4	2.1	1.5	15.0	0.10	0.18	0.01	12.0	78.0	31.3	3.57	8.7	15.0	0.07	5.0	1.13	224	4.3	0.02	31.0	0.020	2.2	0.30	0.40	6.0	0.1	0.12	0.1	2.5	88.0	1.0	48.9			
1401	443389	7764004	26.5	52.0	4.41	206.3	4.4	1.5	43.0	0.10	0.14	0.01	55.0	116.0	174.4	10.6	12.2	24.0	0.09	5.0	2.59	1755	0.1	0.01	84.0	0.052	1.5	10.60	0.90	5.0	0.2	1.0	0.06	0.1	2.5	123.0	3.0	152.0		
1402	443201	7764000	18.5	55.0	2.09	7.2	1.0	1.5	6.0	0.10	0.04	0.01	19.0	788.0	7.2	3.54	10.4	5.0	0.03	1.0	2.54	348	0.1	0.01	159.0	0.15	2.0	1.50	1.0	1.0	0.2	1.0	0.06	0.1	2.5	72.0	1.0	47.9		
1403	443001	7764000	24.1	53.0	3.00	66.5	5.1	1.5	63.0	0.10	0.03	0.09	47.0	128.0	75.0	9.45	8.8	37.0	0.02	7.0	1.48	2190	0.8	0.01	93.0	0.046	1.7	14.20	1.30	2.0	0.3	1.0	0.05	0.1	2.5	114.0	1.0	84.8		
1404	442800	7764001	42.5	50.0	2.61	24.7	2.7	1.5	29.0	0.10	0.19	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.69	636	1.3	0.01	71.0	0.056	2.2	1.10	1.10	4.0	0.1	0.05	0.1	2.5	61.0	1.0	80.2			
1405	442898	7764000	41.8	41.0	2.51	2.6	2.0	4.0	5.0	0.10	0.02	0.01	20.0	59.0	52.5	4.98	9.9	14.0	0.01	4.0	1.48	538	0.2	0.01	21.0	0.041	2.3	0.50	0.70	7.0	0.1	0.02	0.1	2.5	128.0	1.0	57.5			
1406	442389	7764004	30.0	91.0	2.23	9.8	2.3	1.0	2.0	0.10	0.01	0.01	16.0	72.0	24.9	5.80	13.2	18.0	0.01	3.0	1.06	224	0.5	0.01	44.0	0.031	1.1	0.80	0.60	1.0	0.1	0.02	0.1	2.5	143.0	1.0	56.9			
1407	442200	7763989	16.8	64.0	4.51	18.6	4.4	1.5	7.0	0.10	0.16	0.09	52.0	53.0	129.3	12.02	21.0	25.0	0.02	8.0	2.65	1732	0.3	0.01	48.0	0.092	2.5	9.70	0.60	5.0	0.1	0.03	0.1	2.5	336.0	1.0	168.0			
1408	441996	7763986	40.3	15.0	3.61	54.1	4.1	1.5	49.0	0.10	0.15	0.08	47.0	142.0	222.7	8.02	12.0	28.0	0.01	12.0	2.57	1756	0.3	0.01	110.0	0.069	1.8	7.40	0.70	6.0	0.1	0.03	0.1	2.5	161.0	1.0	121.1			
1409	441799	7764002	14.4	54.0	3.89	171.8	1.8	6.0	28.0	0.10	0.09	0.024	73.0	111.0	233.8	12.70	16.6	34.0	0.02	6.0	1.99	4471	0.5	0.01	121.0	0.082	3.1	28.60	1.70	4.0	0.2	1.0	0.03	0.1	2.5	139.0	1.0	143.7		
1410	D	441587	7764002	24.5	36.0	3.89	33.3	3.5	2.0	29.0	0.10	0.19	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.69	636	1.3	0.01	94.0	0.070	2.0	13.20	0.50	4.0	0.1	0.04	0.1	2.5	161.0	1.0	113.4		
1410	D	441587	7764002	22.0	46.4	5.1	40.0	5.1	1.5	14.0	0.50	0.08	0.11	52.0	59.0	52.5	4.98	9.9	14.0	0.01	4.0	1.48	538	0.2	0.01	21.0	0.041	2.3	11.50	1.90	4.0	0.1	0.03	0.3	2.5	193.0	1.0	98.7		
1411	441400	7764003	18.8	15.0	3.92	26.5	0.4	1.0	10.0	0.10	0.11	0.04	39.0	11.0	160.3	9.17	12.5	57.0	0.02	4.0	2.31	1645	0.4	0.01	74.0	0.068	1.4	2.70	0.90	4.0	0.1	0.04	0.4	2.5	156.0	1.0	102.2			
1412	440212	7764006	17.3	125.0	4.90	366.9	1.0	1.5	1.4	12.0	0.10	0.28	0.39	72.0	158.0	415.9	11.17	17.8	78.0	0.07	8.0	3.38	2286	0.7	0.01	126.0	0.052	3.4	7.40	0.80	9.0	0.2	0.04	0.4	2.5	263.0	1.0	151.3		
1413	440002	7763986	13.1	68.0	4.99	277.7	1.9	14.0	1.2	31.0	0.10	0.22	0.08	44.0	146.0	232.6	8.38	10.3	38.0	0.02	6.0	1.91	2848	1.8	0.01	94.0	0.048	2.5	9.70	0.60	5.0	0.1	0.03	0.2	2.5	153.0	1.0	111.1		
1414	441195	7764000	21.9	57.0	3.83	73.5	3.1	1.5	2.4	13.0	0.10	0.23	0.01	40.0	128.0	149.9	9.43	12.8	27.0	0.03	4.0	2.93	984	0.7	0.01	77.0	0.054	0.9	1.70	0.15	7.0	0.1	0.05	0.1	2.5	197.0	2.0	130.3		
1414	439793	7763988	22.1	49.0	3.03	119.1	3.6	1.5	6.0	68.0	0.10	0.18	0.02	50.0	91.0	229.6	8.70	11.8	26.0	0.03	5.0	2.62	826	0.6	0.01	67.0	0.040	2.3	3.20	0.40	9.0	0.1	0.05	0.2	2.5	156.0	2.0	137.3		
1420	D	439888	7764002	23.1	48.0	3.02	42.8	10.6	1.5	6.0	63.0	0.10	0.11	0.13	30.0	94.0	106.4	8.55	10.9	55.0	0.17	4.0	1.79	2159	0.9	0.01	59.0	0.059	2.7	5.80	1.80	4.0	0.1	0.07	0.1	2.5	147.0	1.0	121.6	
1420	D	439888	7764007	19.0	70.0	3.61	81.6	0.3	1.5	68.0	0.10	0.18																												

## C-horizon Ringvassøy 1988

Sample	FDnE34ep89	mN34ep89	Fine	Ag	Al	As	Au	B	Ba	Bi	Ca	Cd	Co	Cr	Cu	Fe	Ga	Hg	K	La	Mg	Mn	Mo	Na	Ni	P	Pb	Sb	Se	Si	Te	Th	Ti	U	V	W	Zn	
1381	441638	7771734	10.5	15.0	2.26	10.3	1.5	5.0	33.0	0.10	0.38	0.03	22.0	56.0	102.8	3.92	8.6	18.0	0.17	13.0	0.16	60.1	0.02	38.0	0.086	9.7	0.40	1.40	25.0	0.1	2.0	0.09	0.1	2.5	68.0	1.0	62.6	
1382	441652	7771691	9.4	15.0	2.78	7.0	14.7	1.5	19.0	0.10	0.33	0.01	11.0	44.0	34.4	2.62	5.3	44.0	0.10	8.0	0.77	26.2	0.02	24.0	0.075	7.1	0.40	1.40	25.0	0.1	2.0	0.09	0.1	2.5	38.0	1.0	49.1	
1383	441700	7771562	42.0	88.0	1.68	23.8	2.2	1.5	19.0	0.10	0.32	0.03	11.0	43.0	32.5	2.75	10.9	13.0	0.07	5.0	1.01	24.2	2.0	2.02	27.0	0.007	8.2	0.40	0.60	36.0	0.1	1.0	0.18	0.3	2.5	62.0	1.0	52.9
1384	438807	7765058	31.1	15.0	3.02	42.7	16.8	1.5	20.0	0.10	0.43	0.14	58.0	106.0	212.4	5.66	8.9	16.0	0.05	16.0	0.04	6.0	0.04	24.0	0.066	2.8	0.70	0.90	15.0	0.1	2.0	0.09	0.2	6.0	122.0	1.0	91.0	
1385	438888	7765113	18.0	15.0	1.35	67.5	2.6	1.5	19.0	0.10	0.37	0.14	63.0	59.0	148.5	3.46	4.7	5.0	0.09	8.0	0.83	1419	0.02	38.0	0.109	2.8	0.90	0.40	12.0	0.1	1.0	0.06	0.3	2.5	101.0	1.0	55.7	
1386	438890	7765162	43.5	15.0	1.27	23.2	5.9	1.5	9.0	0.10	0.37	0.06	35.0	53.0	112.4	2.96	3.9	14.0	0.02	6.0	0.87	762	0.02	34.0	0.094	1.6	0.40	0.15	10.0	0.1	1.0	0.05	0.1	2.5	163.0	1.0	39.8	
1387	441567	7766442	31.9	53.0	3.07	11.0	4.3	1.5	24.0	0.10	0.31	0.21	41.0	89.0	142.7	6.84	10.7	28.0	0.10	6.0	1.16	116.0	0.01	2.8	0.80	1.17	5.0	0.07	8.0	0.1	0.07	0.2	2.5	163.0	1.0	108.5		
1388	441348	7765044	22.3	52.0	2.37	31.9	10.2	1.0	30.0	0.20	0.37	0.23	53.0	82.0	245.0	5.63	8.0	28.0	0.08	8.0	1.72	1615	0.02	54.0	0.135	3.2	1.20	0.15	10.0	0.1	2.0	0.06	0.2	2.5	137.0	2.0	101.6	
1389	441375	7760333	18.3	60.0	3.41	24.2	9.6	1.5	63.0	0.70	0.43	0.24	72.0	109.0	243.9	7.93	11.1	44.0	0.12	6.0	2.84	1876	0.01	81.0	1.40	3.4	0.60	0.15	10.0	0.2	1.0	0.08	0.2	2.5	173.0	1.0	134.7	
1390	427400	7768150	44.8	54.0	1.08	23.2	2.7	1.5	13.0	0.10	0.33	0.02	22.0	44.0	102.9	2.61	4.3	18.0	0.03	6.0	0.68	816	0.01	32.0	0.077	1.6	0.30	0.15	8.0	0.1	0.05	0.1	2.5	61.0	1.0	30.2		
1391	427400	7769050	37.1	54.0	2.21	44.2	5.7	1.5	10.0	0.10	0.16	0.03	12.0	83.0	22.4	4.47	12.3	31.0	0.05	4.0	1.14	236	14.6	0.02	28.0	0.018	3.4	0.40	0.40	6.0	0.1	0.05	0.1	2.5	130.0	1.0	48.2	
1392	427400	7768956	35.0	54.0	2.01	19.4	2.1	1.5	15.0	0.10	0.18	0.01	12.0	78.0	31.3	3.57	8.7	15.0	0.07	5.0	1.13	224	4.3	0.02	31.0	0.020	2.2	0.30	0.40	6.0	0.1	0.12	0.1	2.5	143.0	1.0	48.9	
1401	443389	7764004	26.0	52.0	4.41	20.6	4.4	1.5	43.0	0.10	0.14	0.01	55.0	116.0	174.4	10.6	12.2	24.0	0.09	5.0	2.58	1755	0.01	15.0	0.052	1.5	10.60	0.90	5.0	0.2	1.0	0.06	0.1	2.5	213.0	3.0	152.0	
1402	443201	7764000	18.5	54.0	2.09	7.2	1.0	1.5	6.0	0.10	0.04	0.01	19.0	788.0	7.2	3.54	10.4	5.0	0.03	1.0	2.54	348	0.1	0.01	159.0	0.015	2.0	1.50	0.15	1.0	0.2	1.0	0.06	0.1	2.5	72.0	1.0	47.9
1403	443001	7764000	24.1	53.0	3.00	9.6	5.1	1.5	10.0	0.10	0.03	0.09	47.0	128.0	75.0	9.45	8.8	37.0	0.02	7.0	1.48	2190	0.01	93.0	0.046	1.7	14.20	1.30	2.0	0.3	1.0	0.05	0.1	2.5	114.0	1.0	84.8	
1404	442800	7764001	42.5	54.0	2.61	44.7	2.7	1.5	29.0	0.10	0.19	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.68	636	1.3	0.01	71.0	0.056	2.2	10.10	1.10	4.0	0.1	0.05	0.1	2.5	61.0	1.0	80.2	
1405	442898	7764000	41.8	41.0	2.51	2.6	2.0	4.0	5.0	0.10	0.02	0.01	58.0	52.5	4.98	9.9	14.0	0.01	4.0	1.48	538	0.2	0.01	21.0	0.041	2.3	0.50	0.70	1.0	0.1	0.02	0.1	2.5	128.0	1.0	57.5		
1406	442899	7764004	30.0	91.0	2.23	9.8	2.3	1.5	24.0	0.10	0.01	0.01	16.0	72.0	24.9	5.80	13.2	18.0	0.01	3.0	1.06	224	0.5	0.01	44.0	0.031	1.1	0.80	0.60	1.0	0.1	0.02	0.1	2.5	143.0	1.0	56.9	
1407	442200	7763989	16.8	64.0	4.51	18.6	4.4	1.5	7.0	0.10	0.16	0.09	52.0	53.0	129.3	12.02	21.0	25.0	0.02	8.0	2.65	1732	0.3	0.01	48.0	0.092	2.5	9.70	0.60	5.0	0.1	0.03	0.1	2.5	336.0	1.0	168.0	
1408	441996	7763986	40.3	54.0	1.61	51.1	4.1	1.5	49.0	0.10	0.15	0.08	47.0	142.0	222.7	8.02	12.0	28.0	0.01	12.0	2.57	1756	0.3	0.01	110.0	0.069	1.8	7.40	0.90	6.0	0.1	0.03	0.1	2.5	161.0	1.0	121.1	
1409	441799	7764002	14.4	54.0	3.89	171.8	1.8	6.0	28.0	0.10	0.09	0.24	73.0	111.0	233.8	12.70	16.6	34.0	0.02	6.0	1.99	4471	0.5	0.01	121.0	0.082	3.1	28.60	1.70	4.0	0.2	1.0	0.03	0.1	2.5	139.0	1.0	143.7
1410	D	441587	7764002	24.5	36.0	3.89	33.3	3.5	2.0	29.0	0.10	0.19	0.01	31.0	73.0	133.8	6.16	7.5	19.0	0.11	6.0	1.68	636	1.3	0.01	94.0	0.070	2.2	13.20	0.50	4.0	0.1	0.04	0.1	2.5	161.0	1.0	113.4
1410	D	441587	7764002	22.0	46.4	5.1	40.0	5.1	1.5	14.0	0.50	0.08	0.11	52.0	50.0	52.5	4.98	9.9	14.0	0.01	4.0	1.50	1889	0.6	0.01	70.0	0.065	1.9	11.50	0.40	4.0	0.1	0.03	0.3	2.5	193.0	1.0	98.7
1411	441400	7764003	18.8	15.0	3.92	26.5	0.4	1.5	18.0	0.10	0.11	0.04	39.0	11.0	160.3	9.1	18.7	25.0	0.02	4.0	2.31	1645	0.4	0.01	74.0	0.068	1.4	2.70	0.90	4.0	0.1	0.03	0.1	2.5	156.0	1.0	102.2	
1412	440212	7764006	17.3	125.0	4.90	366.9	1.0	1.5	18.0	0.10	0.28	0.39	72.0	158.0	415.9	11.17	17.8	70.0	0.07	8.0	3.38	2286	0.7	0.01	126.0	0.052	3.4	7.40	0.80	9.0	0.2	0.04	0.2	2.5	263.0	1.0	151.3	
1413	440002	7763986	13.1	68.0	4.99	27.7	1.9	14.0	12.0	0.10	0.22	0.07	38.0	109.0	90.5	8.65	11.8	26.0	0.03	5.0	2.62	826	0.6	0.01	67.0	0.040	2.3	3.20	0.40	9.0	0.1	0.05	0.1	2.5	156.0	2.0	111.1	
1414	441495	7763987	26.5	93.0	4.25	30.1	2.4	1.5	17.0	0.10	0.23	0.01	40.0	146.0	149.9	9.43	14.0	42.0	0.02	6.0	1.91	2848	1.8	0.01	110.0	0.086	3.4	5.80	2.80	4.0	0.2	0.04	0.2	2.5	143.0	2.0	130.3	
1415	440598	7763988	22.1	49.0	3.03	119.1	3.6	1.5	68.0	0.10	0.11	0.13	30.0	94.0	106.4	8.55	10.9	55.0	0.17	4.0	1.79	2159	0.9	0.01	59.0	0.059	2.7	5.80	1.80	4.0	0.1	0.07	0.1	2.5	159.0	1.0	147.0	
1416	440401	7764007	19.0	70.0	3.61	81.6	0.3	1.5	22.0	0.10	0.18	0.18	57.0	43.0	127.7	7.69	9.6	29.0	0.09	5.0	1.65	1042	0.1	0.01	45.0	0.036	4.2	10.00	0.40	6.0	0.1	0.09	0.2	2.5	231.0	1.0	108.3	
1421	443789	7764007	15.6	89.0	4.37	92.1	9.3	1.5	47.0	0.10	0.25	0.15	147.0	150.0	308.8	8.60	10.3	53.0	0.11	5.0	2.82	1513	0.4	0.01	54.0	0.031	6.0	0.50	0.90	14.0	0.1	0.09	0.2	2.5	137.0	1.0	131.2	
1422	444																																					

